

```

DDDDDDDDDDDDDD RRRRRRRRRRRR IIIIIIIIII VVV VVV EEEEEEEEEEEEEEE RRRRRRRRRRRR
DDDDDDDDDDDDDD RRRRRRRRRRRR IIIIIIIIII VVV VVV EEEEEEEEEEEEEEE RRRRRRRRRRRR
DDDDDDDDDDDDDD RRRRRRRRRRRR IIIIIIIIII VVV VVV EEEEEEEEEEEEEEE RRRRRRRRRRRR
DDD DDD DDD RRR RRR RRR VVV VVV EEE RRR RRR
DDD DDD DDD RRR RRR RRR VVV VVV EEE RRR RRR
DDD DDD DDD RRR RRR RRR VVV VVV EEE RRR RRR
DDD DDD DDD RRR RRR RRR VVV VVV EEE RRR RRR
DDD DDD DDD RRR RRR RRR VVV VVV EEE RRR RRR
DDD DDD DDD RRR RRR RRR VVV VVV EEE RRR RRR
DDD DDD DDD RRRRRRRRRRRR IIIIIIIIII VVV VVV EEEEEEEEEEEEE RRRRRRRRRRRR
DDD DDD DDD RRRRRRRRRRRR IIIIIIIIII VVV VVV EEEEEEEEEEEEE RRRRRRRRRRRR
DDD DDD DDD RRRRRRRRRRRR IIIIIIIIII VVV VVV EEEEEEEEEEEEE RRRRRRRRRRRR
DDD DDD DDD RRR RRR IIIIIIIIII VVV VVV EEE RRR RRR
DDD DDD DDD RRR RRR IIIIIIIIII VVV VVV EEE RRR RRR
DDD DDD DDD RRR RRR IIIIIIIIII VVV VVV EEE RRR RRR
DDD DDD DDD RRR RRR RRR IIIIIIIIII VVV VVV EEE RRR RRR
DDD DDD DDD RRR RRR RRR IIIIIIIIII VVV VVV EEE RRR RRR
DDD DDD DDD RRR RRR RRR IIIIIIIIII VVV VVV EEE RRR RRR
DDDDDDDDDDDDDD RRR RRR RRR IIIIIIIIII VVV VVV EEEEEEEEEEEEE RRR RRR
DDDDDDDDDDDDDD RRR RRR RRR IIIIIIIIII VVV VVV EEEEEEEEEEEEE RRR RRR
DDDDDDDDDDDDDD RRR RRR RRR IIIIIIIIII VVV VVV EEEEEEEEEEEEE RRR RRR

```

[illegible]

```
XX      XX  MM      MM  DDDDDDDD  RRRRRRRR  IIIIII  VV      VV  EEEEEEEEE  RRRRRRRR
XX      XX  MM      MM  DDDDDDDD  RRRRRRRR  IIIIII  VV      VV  EEEEEEEEE  RRRRRRRR
XX      XX  MMMM    MMMM DD      DD  RR      RR  III      III  VV      VV  EE      EE  RR      RR
XX      XX  MM      MM  DD      DD  RR      RR  III      III  VV      VV  EE      EE  RR      RR
  XX    XX  MM      MM  DD      DD  RR      RR  III      III  VV      VV  EE      EE  RR      RR
    XX    MM      MM  DD      DD  RRRRRRRR  III      III  VV      VV  EEEEEEEE  RRRRRRRR
  XX    MM      MM  DD      DD  RRRRRRRR  III      III  VV      VV  EEEEEEEE  RRRRRRRR
    XX    MM      MM  DD      DD  RR      RR  III      III  VV      VV  EE      EE  RR      RR
  XX    MM      MM  DD      DD  RR      RR  III      III  VV      VV  EE      EE  RR      RR
XX      XX  MM      MM  DD      DD  RR      RR  III      III  VV      VV  EE      EE  RR      RR
XX      XX  MM      MM  DDDDDDDD  RR      RR  IIIIII  VV      VV  EEEEEEEEE  RR      RR
XX      XX  MM      MM  DDDDDDDD  RR      RR  IIIIII  VV      VV  EEEEEEEEE  RR      RR
                                     ....
                                     ....
                                     ....
                                     ....
```

```
LL      IIIIII  SSSSSSSS
LL      IIIIII  SSSSSSSS
LL      II      SS
LL      II      SS
LL      II      SS
LL      II      SS
LL      II      SSSSSS
LL      II      SSSSSS
LL      II      SS
LL      II      SS
LL      II      SS
LL      II      SS
LLLLLLLLLL  IIIIII  SSSSSSSS
LLLLLLLLLL  IIIIII  SSSSSSSS
```


(3)	354	Standard Driver Tables
(4)	432	UNIT_INIT - Initialize the device unit
(5)	469	XMIT_FDT - Transmit I/O FDT routine
(6)	610	RCV_FDT - Receive I/O FDT routine
(7)	693	ALT_FDT - Alternate Transmit/Receive I/O routine
(8)	744	SETMODE_FDT - Set mode I/O operation FDT dispatch routine
(9)	904	SETMODE_FDT_LINE - Set mode I/O operation FDT routine for LINE
(10)	998	SENSEMODE - Sense mode I/O operation FDT
(11)	1105	STARTIO - Start setmode I/O operation
(12)	1179	STARTUP - Start up controller
(13)	1494	CHANGE_MODE - Change mode and characteristics
(14)	1536	FILLRCVLIST - Fill receive buffer list
(15)	1600	START_RECEIVE - Start any receives
(16)	1654	LOAD_PORT - Load controller input port
(17)	1759	PORT_INTR - Input port ready interrupt service routine
(18)	1820	CONTROL_INTR - Control out interrupt service routine
(19)	1922	SCHED_FORK - Schedule the fork process
(20)	1965	FORK_PROC - Error and I/O completion fork process
(21)	2052	FINISH_RCV_IO - Finish receive I/O processing
(22)	2107	REGDUMP - Error log and diagnostics register dump
(23)	2142	POKE_USER - Poke user process on attention condition
(24)	2190	TIMEOUT - Transmit timeout handler
(25)	2219	DEVICE_ERROR - Device error handler
(26)	2283	SHUTDOWN - Shut down device
(26)	2284	CANCEL - Cancel I/O and Deassign Routine
(27)	2492	DISABLE_MODEM - DISABLE THE MODEM LINE DTR


```
0000 1 .TITLE XMDRIVER - VAX/VMS DMC11/DMR11 Device Driver
0000 2 .IDENT 'V04-000'
0000 3
0000 4 *****
0000 5
0000 6 * COPYRIGHT (c) 1978, 1980, 1982, 1984 BY
0000 7 * DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASSACHUSETTS.
0000 8 * ALL RIGHTS RESERVED.
0000 9
0000 10 * THIS SOFTWARE IS FURNISHED UNDER A LICENSE AND MAY BE USED AND COPIED
0000 11 * ONLY IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE AND WITH THE
0000 12 * INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE OR ANY OTHER
0000 13 * COPIES THEREOF MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY
0000 14 * OTHER PERSON. NO TITLE TO AND OWNERSHIP OF THE SOFTWARE IS HEREBY
0000 15 * TRANSFERRED.
0000 16
0000 17 * THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE WITHOUT NOTICE
0000 18 * AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT
0000 19 * CORPORATION.
0000 20
0000 21 * DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS
0000 22 * SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.
0000 23
0000 24 *****
0000 25 *****
0000 26 ++
0000 27 FACILITY:
0000 28
0000 29 VAX/VMS DMC11/DMR11 Device driver
0000 30
0000 31 ABSTRACT:
0000 32
0000 33 This module contains the DMC11/DMR11 driver FDT routines,
0000 34 interrupt dispatcher, interrupt service and fork routines.
0000 35
0000 36 AUTHOR:
0000 37
0000 38 R.HEINEN 24-AUG-77
0000 39
0000 40 MODIFICATION HISTORY:
0000 41
0000 42 V03-023 RNG0023 Rod N. Gamache 17-May-1984
0000 43 Set the DEVSM_AVL bit to make XM units available.
0000 44
0000 45 V03-022 RNG0022 Rod N. Gamache 29-Feb-1984
0000 46 Fix problem with allocation of map registers which causes
0000 47 too many map registers to be allocated.
0000 48
0000 49 V03-021 RNG0021 Rod N. Gamache 29-Oct-1983
0000 50 Fix broken register usage caused by use of TIMEDWAIT macro.
0000 51
0000 52 V03-020 RNG0020 Rod N. Gamache 27-Jul-1983
0000 53 Changed WAIT10 macro to use system TIMEDWAIT macro.
0000 54 Change all NOP wait loops to use TIMEDWAIT macro.
0000 55 Don't do BUG_CHECK if input request was processed by
0000 56 Interrupt Service Routine.
0000 57
```



```
0000 58 : V03-019 ROW0169 Ralph O. Weber 3-MAR-1983
0000 59 : Add $IPLDEF.
0000 60 :
0000 61 : V03-018 RNG0012 Rod Gamache 28-Jan-1983
0000 62 : Add code to hang up modems on LINE DOWN requests.
0000 63 :
0000 64 : V03-017 RNG0011 Rod Gamache 17-Dec-1982
0000 65 : Speed up the startup time for devices that don't run
0000 66 : micro-diagnostics.
0000 67 :
0000 68 : V03-016 RNG0010 Rod Gamache 04-Nov-1982
0000 69 : Setup timeout routine offset for new fork process
0000 70 : added to transmit process routine.
0000 71 :
0000 72 : V03-015 RNG0009 Rod Gamache 07-Sep-1982
0000 73 : Fix cancel routine to only abort user's I/O on $CANCEL
0000 74 : request and not to shutdown device or abort other users'
0000 75 : I/O. Add another fork block to UCB to allow a fork on tranmit
0000 76 : requests - allows users to transmit any size message up to
0000 77 : 16K. Remove the code to pre-allocate one transmit map register.
0000 78 :
0000 79 : V03-013 RNG0008 Rod Gamache 01-Sep-1982
0000 80 : Reduce startup time required in previous enhancement.
0000 81 : Fix startup problem when running in LOOPBACK mode - fixes
0000 82 : problem found by UETP.
0000 83 :
0000 84 : V03-012 RAN0001 R. Newell 08-Jul-1982
0000 85 : Add code to determine whether a DMC has the high-speed or
0000 86 : low-speed microcode chip set and what the mode and interface
0000 87 : switches are set to on a DMR.
0000 88 :
0000 89 :
0000 90 : PREVIOUS MODIFICATIONS:
0000 91 :
0000 92 : Al Eldridge, Scott Davis, Len Kowell, Rod Gamache 1979-1982
0000 93 :--
```



```
0000 95 :  
0000 96 : System definitions  
0000 97 :  
0000 98 $ACBDEF ; AST control block  
0000 99 $CANDEF ; Define Cancel reason codes  
0000 100 $CRBDEF ; Controller request block  
0000 101 $CXBDEF ; Define CXB block  
0000 102 $DCDEF ; Device types  
0000 103 $DDBDEF ; Device data block  
0000 104 $DPTDEF ; Driver prologue table  
0000 105 $DYNDEF ; Dynamic data structure types  
0000 106 $FKBDEF ; Fork block definitions  
0000 107 $IDBDEF ; Interrupt data block  
0000 108 $IODEF ; I/O functions  
0000 109 $IPLDEF ; IPL symbolic definitions  
0000 110 $IRPDEF ; I/O packets  
0000 111 $JIBDEF ; Job information block  
0000 112 $NMADEF ; Network management codes  
0000 113 $PCBDEF ; Process control block  
0000 114 $PRDEF ; Processor registers  
0000 115 $SSDEF ; System status codes  
0000 116 $TQDEF ; Timer Queue Element  
0000 117 $UBADEF ; UNIBUS adapter registers  
0000 118 $UCBDEF ; Unit control block  
0000 119 $VADEF ; Virtual address fields  
0000 120 $VECDEF ; Interrupt vector  
0000 121 $XMDEF ; XMDRIVER symbols  
0000 122 :  
0000 123 :  
0000 124 : Local macros  
0000 125 :  
0000 126 .MACRO SETBIT POS,BAS,?L ; Set a single bit  
0000 127 BBSS POS,BAS,L  
0000 128 L:  
0000 129 .ENDM SETBIT  
0000 130  
0000 131 ;*****  
0000 132  
0000 133 .MACRO CLRBIT POS,BAS,?L ; Clear a single bit  
0000 134 BBCC POS,BAS,L  
0000 135 L:  
0000 136 .ENDM CLRBIT  
0000 137  
0000 138 ;*****  
0000 139  
0000 140 .MACRO ADDLC COUNT,COUNTER,?L; Add to counter  
0000 141 ADDL COUNT,COUNTER ; Increment  
0000 142 BCC L ; Br if no carry  
0000 143 MNEGL #1,COUNTER ; Set to maximum value  
0000 144 L:  
0000 145 .ENDM ADDLC  
0000 146  
0000 147 ;*****  
0000 148  
0000 149 .MACRO WAIT10 WTIME,?L1  
0000 150  
0000 151 TIMEDWAIT TIME=WTIME,-
```



```
0000 152      INS1=<BITB      S^#0,S^#0>,-
0000 153      INS2=<BNEQ    L1>,-
0000 154      DONELBL=L1
0000 155
0000 156      .ENDM  WAIT10
0000 157
0000 158      ;*****
0000 159
0000 160      .MACRO  COUNTER TYPE,BITMAP=NO,WIDTH=8,-
0000 161                  BASEOFF1=0,UCBOFF1=DEV CNT,BASEOFF2=0,UCBOFF2=DEV CNT
0000 162      $$$TYP = NMASC CTCIR 'TYPE' & NMASM CNT TYP
0000 163      .IIF IDN <BITMAP><YES>, $$$TYP = $$$TYP!<NMASM CNT MAP>
0000 164      $$$WID = 0      ; Set reserved mask field
0000 165      .IIF IDN <WIDTH><8>, $$$WID = <1@NMASV CNT WID>
0000 166      .IIF IDN <WIDTH><16>, $$$WID = <2@NMASV CNT WID>
0000 167      .IIF IDN <WIDTH><32>, $$$WID = <3@NMASV CNT WID>
0000 168      .IIF EQ $$$WID, .ERROR      ; Invalid bit width value
0000 169      .WORD  NMASM CNT_COU!$$$WID!$$$TYP
0000 170      .IF  NE BASEOFF1
0000 171                  .BYTE BASEOFF1,UCBSB_XM_'UCBOFF1'-UCBSB_XM_DEV CNT
0000 172      .IIF NE BASEOFF2, .BYTE BASEOFF2,UCBSB_XM_'UCBOFF2'-UCBSB_XM_DEV CNT
0000 173                  .BYTE 0
0000 174      .ENDC
0000 175      CNT_BUFSIZ = CNT_BUFSIZ + 2 + <WIDTH/8>
0000 176      .IIF IDN <BITMAP><YES>, CNT_BUFSIZ = CNT_BUFSIZ + 2
0000 177      .ENDM  COUNTER
0000 178
0000 179      ;
0000 180      ; Local symbol definitions
0000 181      ;
0000 182      ;
0000 183      ;
0000 184      ; $QIO parameter offsets
0000 185      ;
00000000 0000 186 P1      = 0      ; Parameter 1
00000004 0000 187 P2      = 4      ; Parameter 2
00000008 0000 188 P3      = 8      ; Parameter 3
0000 189
00000100 0000 190 BASETAB SIZE      = 256      ; Size of base table
00003FFF 0000 191 MAX_C_BUFSIZE      = 16383      ; Maximum transfer size
00000007 0000 192 MAX_RCV      = 7      ; Maximum number outstanding receives
00000007 0000 193 MAX_XMT      = 7      ; Maximum number outstanding transmits
00000003 0000 194 DMC_DMR      = 3      ; DMC or DMR test value
000F4240 0000 195 SHUT_TIME      = 1000*1000      ; Shutdown delay time (100 ms)
00002296 0000 196 UINST_CNF      = ^021226      ; Microinstruction to get config
0000814D 0000 197 UINST_RROM      = ^0100515      ; Microinstruction to read DMC ROM
00000390 0000 198 LS_UCODE      = ^01620      ; Contents of addr 0115 in l.s. u-code
0000A40B 0000 199 DROP_DTR      = ^0122013      ; Drop DTR on modem
00000082 0000 200 EXECUTE_UC      = ^0202      ; Execute in DMC PORT
0000 201      ;
0000 202      ; XMDRIVER UCB extensions
0000 203      ;
0000 204      ; $DEFINI
00000090 0000 205 . = UCB$C_LENGTH
0000 206
0000 207 $DEF  UCB$Q_XM_QUEUES      ; Message and I/O request queue heads
0000 208 $DEF  UCB$Q_XM_XMT_REQ .BLKQ 1      ; Transmit I/O requests awaiting start
```



```
0098 209 $DEF UCBSQ_XM_RCV_REQ .BLKQ 1 : Receive I/O requests awaiting message
00A0 210 $DEF UCBSQ_XM_PORT .BLKQ 1 : Transmits/receives awaiting the port
00A8 211 $DEF UCBSQ_XM_XMT_PND .BLKQ 1 : Transmit I/Os given to device
00B0 212 $DEF UCBSQ_XM_RCV_PND .BLKQ 1 : Receive buffers given to device
00B8 213 $DEF UCBSQ_XM_POST .BLKQ 1 : Transmits/receives awaiting posting
00C0 214 $DEF UCBSQ_XM_RCV_BUF .BLKQ 1 : Free receive buffers
00C8 215 $DEF UCBSQ_XM_RCV_MSG .BLKQ 1 : Receive buffers containing messages
00000008 00D0 216 UCBSQ_XM_QUEUES = <.-UCBSQ_XM_QUEUES>/8 : Number of queue heads
00D0 217
00D0 218 $DEF UCBSL_XM_RCV_MAP .BLKL MAX_RCV : Receive mapping vector
00EC 219 $DEF UCBSL_XM_XMT_MAP .BLKL MAX_XMT : Transmit mapping vector
0108 220 $DEF UCBSB_XM_RCV_MAP .BLKB 1 : Receive mapping in use flags
0109 221 $DEF UCBSB_XM_XMT_MAP .BLKB 1 : Transmit mapping in use flags
010A 222 $DEF UCBSB_XM_RCV_MAX .BLKB 1 : Maximum concurrent receives
010B 223 $DEF UCBSB_XM_XMT_MAX .BLKB 1 : Maximum concurrent transmits
010C 224
00000110 010C 225 $DEF UCBSW_XM_QUOTA .BLKW 1 : Starter's byte quota deducted
010E 226 : (spare for alignment)
0110 227 $DEF UCBSL_XM_PID .BLKL 1 : Starter's process ID
0114 228 $DEF UCBSL_XM_AST .BLKL 1 : Attention AST list
0118 229 $DEF UCBSL_XM_BASSETAB .BLKL 1 : Base table address
011C 230 $DEF UCBSL_XM_BASEMAP .BLKL 1 : Base table map register number/count
0120 231
0120 232 $DEF UCBSL_XM_DRVCNT : Driver counters
0120 233 $DEF UCBSL_XM_RCVBYTCNT .BLKL 1 : Receive byte count
0124 234 $DEF UCBSL_XM_XMTBYTCNT .BLKL 1 : Transmit byte count
0128 235 $DEF UCBSL_XM_RCVMSGCNT .BLKL 1 : Receive message count
012C 236 $DEF UCBSL_XM_XMTMSGCNT .BLKL 1 : Transmit message count
00000004 0130 237 UCBSQ_XM_DRVCNT = <.-UCBSL_XM_DRVCNT>/4
0130 238
0130 239 $DEF UCBSB_XM_DEVCNT : Device counters
0130 240 $DEF UCBSB_XM_NBFR .BLKB 1 : NAKs rcvd - no buffer (DMR11)
0131 241 $DEF UCBSB_XM_HCER .BLKB 1 : NAKs rcvd - header BCC error (DMR11)
0132 242 $DEF UCBSB_XM_DCER .BLKB 1 : NAKs rcvd - data BCC error
0133 243 $DEF UCBSB_XM_NBFS .BLKB 1 : NAKs sent - no buffer
0134 244 $DEF UCBSB_XM_HCES .BLKB 1 : NAKs sent - header BCC error
0135 245 $DEF UCBSB_XM_DCES .BLKB 1 : NAKs sent - data BCC error
0136 246 $DEF UCBSB_XM_REPS .BLKB 1 : REPs sent
0137 247 $DEF UCBSB_XM_REPR .BLKB 1 : REPs rcvd
00000008 0138 248 UCBSQ_XM_DEVCNT = <.-UCBSB_XM_DEVCNT>
0138 249
0138 250 $DEF UCBSB_XM_FKB .BLKB FKBSC_LENGTH : Fork process fork block
0150 251 $DEF UCBSW_XM_MODSIG .BLKW 1 : Modem signals
0152 252 $DEF UCBSQ_XM_LENGTH : Size of XMDRIVER UCB
0152 253
00000148 0152 254 . = UCBSB_XM_FKB+FKBSL_FR3
0148 255
0148 256 $DEF UCBSL_XM_LSTPRT .BLKL 1 : Last port value
014C 257 $DEF UCBSL_XM_LSTCSR .BLKL 1 : Last CSR value
0150 258
0150 259 $VIELD UCB,0,<- : XMDRIVER UCBSW_DEVSTS bits
0150 260 <XM_FORK_XMT,,M>,- : Transmit fork block in use
0150 261 <,25,- : reserved
0150 262 <XM_INITED,,M>,- : Unit initialized
0150 263 <,75,- : reserved
0150 264 <XM_NOTIF,,M>,- : Mailbox notified
0150 265 <XM_LOSTERR,,M>,- : Unreported fatal error
```



```
0150 266 <XM_FORK_PEND,,M>,- ; Fork process scheduling in progress
0150 267 >
0150 268
0150 269 $VIELD MOD,0,- ; XMDRIVER UCBSL_DEVDEPEND+3 bits
0150 270 <- ; HARDWARE-MODE BITS (byte)
0150 271 <XM_HIGH,,M>,- ; High speed indicator (DMC/DMR)
0150 272 <XM_DMC,,M>,- ; DMC compatible mode (DMR only)
0150 273 <XM_INTMOD,,M>,- ; Integral modem (DMR only)
0150 274 <XM_V.35,,M>,- ; V.35 (DMR only)
0150 275 <XM_RS232,,M>,- ; RS-232C mode (DMR only)
0150 276 <XM_RS422,,M>,- ; RS-422 mode (DMR only)
0150 277 <,15>- ; RESERVED
0150 278 <XM_BSEL1,,M>,- ; Indicates that BSEL1 is not locked out
0150 279 > ; ..if set, indicates 1st 2 bits are ok
0150 280
0150 281 ;
0150 282 ; DMC11/DMR11 device register definitions
0150 283 ;
00000000 0150 284 = 0
0000 285 $DEF XM_I_CSR .BLKW 1 ; Input CSR (SEL 0)
0002 286 _VIELD XM_I,0,<- ;
0002 287 <TYPE,,M>,- ; Request type
0002 288 <RCV,,M>,- ; Receive buffer flag
0002 289 <,2>- ; reserved
0002 290 <RQI,,M>,- ; Request port
0002 291 <IEI,,M>,- ; Port available interrupt enable
0002 292 <RDI,,M>,- ; Port available
0002 293 <STEPUP,,M>,- ; Step microprocessor
0002 294 <ROMI,,M>,- ; ROM IN
0002 295 <ROMO,,M>,- ; ROM OUT
0002 296 <LOOPB,,M>,- ; Internal loopback
0002 297 <,2>- ; Maintenance bits
0002 298 <MCLR,,M>,- ; Master clear device
0002 299 <RUN,,M>,- ; Run
0002 300 >
0002 301 $DEF XM_O_CSR .BLKW 1 ; Output CSR (SEL 2)
0004 302 _VIELD XM_O,0,<- ;
0004 303 <TYPE,,M>,- ; Output type
0004 304 <RCV,,M>,- ; Receive buffer flag
0004 305 <,3>- ; reserved
0004 306 <IEO,,M>,- ; Output interrupt enable
0004 307 <RDO,,M>,- ; Output ready
0004 308 >
0004 309 $DEF XM_PORT .BLKW 1 ; Data port register (SEL 4)
0006 310 $DEF XM_UCODE .BLKW 1 ; Data/error port register (SEL 6)
0008 311 _VIELD XM_E,0,<- ;
0008 312 <DCHK,,M>,- ; Data check
0008 313 <TIMO,,M>,- ; Timeout
0008 314 <NOBUF,,M>,- ; Data overrun
0008 315 <MOP,,M>,- ; MOP message received
0008 316 <LOST,,M>,- ; Lost data
0008 317 <TRNER,,M>,- ; Transfer error
0008 318 <LINEDWN,,M>,- ; Line down
0008 319 <START,,M>,- ; Start received
0008 320 <NONEXMEM,,M>,- ; Non-existent memory
0008 321 <PROCERR,,M>,- ; Procedure error
0008 322 <POWER,,M>,- ; System powerfailure (set by driver)
```



```
0008 323 <TIMEOUT,,M>.- ; Transmit timeout (set by driver)
0008 324 >
0008 325 ;
0008 326 ; Receive buffer definition
0008 327 ;
0008 328 $DEFINI RCV
00000000 0000 329 . = 0
0000 330 $DEF RCV_L_LINK .BLKL 2 ; Forward and backward queue links
0008 331 $DEF RCV_W_BLKSIZE .BLKW 1 ; Total block size
000A 332 $DEF RCV_B_BLKTYPE .BLKB 1 ; Block type
000B 333 $DEF RCV_B_MAPSLOT .BLKB 1 ; Mapping slot number
000C 334 $DEF RCV_L_BACC .BLKL 1 ; Buffer address / character count
00000048 0010 335 .IIF [T.-CXB$C_HEADER, . = CXB$C_HEADER ; (allow for CXB header)
0048 336 $DEF RCV_T_DATA ; Receive data
0048 337
0048 338 $DEFEND RCV
0008 339
0008 340 ;
0008 341 ; Basetable block definition
0008 342 ;
0008 343 $DEFINI BAS
00000000 0000 344 . = 0
0000 345 $DEF BAS_Q_SPARE .BLKQ 1 ; Spare quadword
0008 346 $DEF BAS_W_SIZE .BLKW 1 ; Block size
000A 347 $DEF BAS_B_TYPE .BLKB 1 ; Block type
000B 348 $DEF BAS_B_SPARE .BLKB 1 ; Spare byte
000C 349 $DEF BAS_T_DATA ; Start of real basetable
000C 350 $DEF BAS_C_HEADER ; Size of base table header
000C 351
000C 352 $DEFEND BAS
```



```
0008 354 .SBTTL Standard Driver Tables
0008 355 :
0008 356 : Driver Prologue Table
0008 357 :
0008 358 DPTAB - :
0008 359 END=XM_END,- : End of driver
0008 360 ADAPTER=UBA,- : UNIBUS device
0008 361 UCBSIZE=UCB$C_XM_LENGTH,- : UCB size
0008 362 NAME=XMDRIVER : Driver name
0038 363
0038 364 DPT_STORE INIT : Initialization data
0038 365 DPT_STORE UCB,UCB$B_FIPL,B,8 : Fork IPL
003C 366 DPT_STORE UCB,UCB$B_DIPL,B,21 : Device IPL
0040 367 DPT_STORE UCB,UCB$B_DEVCHAR,L,<- : Device characteristics
0040 368 DEV$M_NET!DEV$M_AVL!DEV$M_IDV!DEV$M_ODV>
0047 369 DPT_STORE UCB,UCB$B_DEVCLASS,B,DC$ SCOM : Device class
004B 370 DPT_STORE UCB,UCB$B_DEVTYPE,B,DT$ DMC11 : Assume a DMC11
004F 371 DPT_STORE UCB,UCB$W_DEVBUFSIZ,W,256 : Default buffer size
0054 372
0054 373 DPT_STORE REINIT : Initialization data also for reload
0054 374 DPT_STORE DDB,DDBSL_DDT,D,XMSDDT : Driver dispatch table
0059 375 DPT_STORE CRB,CRBSL_INTD+4,D,PORT_INTR : Port interrupt service routine
005E 376 DPT_STORE CRB,CRBSL_INTD+VEC$ UNITINIT,D,UNIT_INIT : Unit init routine
0063 377 DPT_STORE CRB,CRBSL_INTD2+4,D,CONTROL_INTR : Control interrupt service
0068 378 DPT_STORE END
0008 379
0008 380 :
0008 381 : Driver Dispatch Table
0008 382 :
0008 383 DDTAB DEVNAM=XM,- : Device name
0008 384 START=STARTIO,- : Start I/O routine
0008 385 FUNCTB=FUNCTABLE,- : Function decision table
0008 386 CANCEL=CANCEL,- : Cancel I/O routine
0008 387 REGDMP=REGDUMP,- : Register dump routine
0008 388 DIAGBF=<32+36>,- : Diagnostic buffer size
0008 389 ALTSTART=ALTFDT : Alternate transmit/receive routine
0038 390 :
0038 391 : Function Decision Table
0038 392 :
0038 393 FUNCTABLE:
0038 394 FUNCTAB,- : Legal functions
0038 395 <WRITEVBLK,WRITELBLK,WRITEPBLK,- : Transmit functions
0038 396 READVBLK,READLBLK,READPBLK,- : Receive functions
0038 397 SETMODE,SETCHAR,- : Set mode functions
0038 398 SENSEMODE,SENSECHAR> : Read and/or clear counters
0040 399 FUNCTAB,- : Buffered I/O functions
0040 400 <READLBLK,READPBLK,READVBLK,- :
0040 401 SETMODE,SETCHAR> :
0048 402 FUNCTAB XMTFDT,- : Transmit function dispatcher
0048 403 <WRITELBLK,WRITEPBLK,WRITEVBLK> :
0054 404 FUNCTAB RCVFDT,- : Receive function dispatcher
0054 405 <READLBLK,READPBLK,READVBLK> :
0060 406 FUNCTAB SETMODEFDT,- : Set mode function dispatcher
0060 407 <SETMODE,SETCHAR> :
006C 408 FUNCTAB SENSEMODEFDT,- : Sense mode function dispatcher
006C 409 <SENSEMODE,SENSECHAR> :
0078 410
```



```
0078 411 :  
0078 412 : Counter ID and format table  
0078 413 :  
0078 414 : Note: the order of this table is related to the UCB counters.  
0078 415 :  
00000000 0078 416 CNT_BUFSIZ = 0  
0078 417 CNTTAB:  
0078 418 COUNTER BRC,NO, 32  
007A 419 COUNTER BSN,NO, 32  
007C 420 COUNTER DBR,NO, 32  
007E 421 COUNTER DBS,NO, 32  
0080 422  
0080 423 COUNTER DEO,YES,8, 4,HCER,5,DCER  
0087 424 COUNTER DEI,YES,8, 7,HCES,8,DCES  
008E 425 COUNTER LBE,YES,8, 6,NBFS  
0093 426 COUNTER RBE,YES,8, 3,NBFR  
0098 427 COUNTER LRT,NO, 8, 9,REPS  
009D 428 COUNTER RRT,NO, 8,10,REPR  
0000 00A2 429 .WORD 0  
00A4 430
```

: Counters maintained by driver
: Bytes received
: Bytes sent
: Data blocks received
: Data blocks sent
: Counters maintained by device
: Data errors outbound
: Data errors inbound
: Local buffer errors
: Remote buffer errors
: Local reply timeouts
: Remote reply timeouts


```
00A4 432      .SBTTL UNIT_INIT - Initialize the device unit
00A4 433      :++
00A4 434      : UNIT_INIT - Initialize the device unit
00A4 435      :
00A4 436      : FUNCTIONAL DESCRIPTION:
00A4 437      :
00A4 438      : This routine is called when the driver is loaded and during powerfailure
00A4 439      : recovery. It sets the unit status to ONLINE. Also, if called during
00A4 440      : powerfail recovery, it shuts down the device.
00A4 441      :
00A4 442      : INPUTS:
00A4 443      :
00A4 444      :     R3 = CSR address
00A4 445      :     R4 = CSR address
00A4 446      :     R5 = UCB address
00A4 447      :
00A4 448      : OUTPUTS:
00A4 449      :
00A4 450      :     R0,R1,R2,R3,R4,R5 preserved
00A4 451      :--
00A4 452      : UNIT_INIT:
00A4 453      : BISW      #UCBSM_ONLINE,UCBSW_STS(R5)      : Initialize the unit
0143 64 A5 10 A8 00A4 453      : MOVW      UCBSB_FIPL(R5),UCBSB_XM_FKB+- : Set software status ONLINE
0143 C5 0B A5 90 00A8 454      :          FKB$B_FIPL(R5)      : Set FORK BLOCK FORK IPL
      63 4000 8F B0 00AE 455      :          #XM_I_M_MCLR,(R3)      :
      14 64 A5 0E62 30 00B3 457      : BSBW      DISABCE-MODEM      : Master clear the controller
      0F 44 A5 05 E1 00B6 458      : BBC       #UCBSV_POWER,UCBSW_STS(R5),10$ : Disable the modem
      53 01 1A 78 00BB 459      : BBC       #XMSV_STS_ACTIVE,-      : Br if not powerfail recovery
      54 01 10 78 00BD 460      :          UCBSL_DEVDEPEND(R5),10$ : Br if not previously active
      0A8E 30 00C0 461      : PUSHR     #^M<R0,R1,R2,R3,R4>      : Save all registers
      1F BB 00C2 462      : ASHL      #XM_E_V_POWER+16,#1,R3 : Indicate powerfail
      53 01 1A 78 00C6 463      : ASHL      #XM_O_V_TYPE+16,#1,R4  : Indicate error
      0A8E 30 00CA 464      : BSBW      SCHED_FORK      : Schedule fork process
      1F BA 00CD 465      : POPR      #^M<R0,R1,R2,R3,R4>      : Restore registers
      05 00CF 466      : RSB
00D0 467      :
      10$:
```



```
00D0 469 .SBTTL XMTFDT - Transmit I/O FDT routine
00D0 470 :++
00D0 471 : XMTFDT - Transmit I/O FDT routine
00D0 472 :
00D0 473 : Functional description:
00D0 474 :
00D0 475 : This routine is called by the SYS$QIO service to dispatch a WRITE I/O
00D0 476 : request.
00D0 477 :
00D0 478 : The QIO parameters for WRITES are:
00D0 479 :
00D0 480 :     P1 = address of the buffer
00D0 481 :     P2 = size of the buffer
00D0 482 :     P3-P6 = (unused)
00D0 483 :
00D0 484 : The buffer is validated for access and locked into the caller's working
00D0 485 : set, a transmit UNIBUS map register set is allocated, the buffer
00D0 486 : is mapped, the device input port is requested, the buffer address and size
00D0 487 : are passed to the device, and finally the I/O request is queued to await
00D0 488 : the completion of the transmit by the device.
00D0 489 :
00D0 490 : If no transmit slot or mapping registers are available, put the I/O request
00D0 491 : into a wait queue. When a transmit in progress completes, it will restart
00D0 492 : the waiting request. Note - this design depends on having at least one set
00D0 493 : of map registers pre-allocated.
00D0 494 :
00D0 495 : For requests specifying IOSM_ENABLMBX the attention mailbox is enabled.
00D0 496 :
00D0 497 : Inputs:
00D0 498 :
00D0 499 :     R0-R2 = scratch registers
00D0 500 :     R3 = I/O packet address
00D0 501 :     R4 = PCB address
00D0 502 :     R5 = UCB address
00D0 503 :     R6 = CCB address
00D0 504 :     R7 = bit number of the I/O function code
00D0 505 :     R8 = address of the FDT table entry for this routine
00D0 506 :     R9-R11 = scratch registers
00D0 507 :     AP = address of first QIO parameter
00D0 508 :
00D0 509 : Outputs:
00D0 510 :
00D0 511 :     R0 = status of transmit request initiation
00D0 512 :
00D0 513 :     R3,R5 are preserved.
00D0 514 : --
00D0 515 XMTFDT:
00D0 516 MOVZWL S^#SS$_BADPARAM,R0 ; Transmit FDT routine
00D0 517 MOVZWL P2(AP),R1 ; Assume bad buffer parameters
00D0 518 BEQL ABORTIO ; Get buffer size
00D0 519 CMPW R1,#MAX_C_BUFSIZE ; Br if zero - abort I/O
00D0 520 BGTRU ABORTIO ; Is buffer too big?
00D0 521 MOVL P1(AP),R0 ; Br if yes - abort I/O
00D0 522 JSB G^EXES$WRITELOCK ; Get user buffer virtual address
00D0 523 ; Check buffer access and lock down
00D0 524 SETIPL UCBSB FIPL(R5) ; (no return means no access)
00D0 525 MOVZWL #SS$_DEVOFFLINE,R0 ; Synch access to UCB
; Assume device is not active
```

50	14	3C	00D0	516
51	04 AC	3C	00D3	517
	2F	13	00D7	518
3FFF	8F	B1	00D9	519
	28	1A	00DE	520
50	6C	D0	00E0	521
00000000	'GF	16	00E3	522
			00E9	523
			00E9	524
50	0084 8F	3C	00ED	525


```

      11 44 0B E1 00F2 526 BBC #XMSV_STS ACTIVE,- ; Br if not active - abort I/O
      07 00F4 527 UCB$$_DEVDEPEND(R5),ABORTIO
      04 20 07 E1 00F7 528 BBC #IOSV_ENABLMBX,- ; Br if mailbox not to be enabled
      44 A5 10 A8 00F9 529 IRPSW_FUNC(R3),5$
      0C 00FC 530 BISW #XMSM_CHR_MBX,UCB$$_DEVDEPEND(R5) ; Enable mailbox
00000000'GF 17 0100 531 5$: BSBB XMT_START ; Start transmit operation
      0102 532 JMP G^EXE$QIORETURN ; Exit QIO service to await completion
      0108 533
00000000'GF 17 0108 534 ABORTIO: ; Abort the I/O request
      010E 535 JMP G^EXE$ABORTIO ; and exit QIO service
      010E 536
      010E 537 ; Start transmit operation.
      010E 538
      010E 539
0094 D5 63 OE 010E 540 XMT_START: ; Start transmit operation
      0113 541 INSQUE (R3),@UCB$$_XM_XMT_REQ+4(R5) ; Insert at end of wait queue
      0113 542
      0113 543 XMT_START_ALT: ; Alternate entry to start xmits
      0113 544 BBS #UCB$$_XM_FORK_XMT,- ; Br if XMT fork block in use
      0115 545 UCB$$_DEVSTS(R5),10$
53 1A 68 A5 0F 0118 546 REMQUE @UCB$$_XM_XMT_REQ(R5),R3 ; Remove first entry from queue
      0090 D5 1D 011D 547 BVS 10$ ; Br if none
      011F 548
      011F 549 ; Find a free mapping register slot. If none currently available, put
      011F 550 ; the I/O request in the wait queue.
      011F 551
54 0109 C5 54 00 EB 011F 552 MOVZBL UCB$$_XM_XMT_MAX(R5),R4 ; Get max concurrent transmits
      006 0124 553 FFC #0,R4,UCB$$_XM_XMT_MAP(R5),R4 ; Find a free transmit slot
      0090 C5 63 OE 012B 554 BNEQ 20$ ; Br if one free
      05 012D 555 INSQUE (R3),UCB$$_XM_XMT_REQ(R5) ; Re-insert request in wait queue
      0132 556 10$: RSB ; Return to caller
      0133 557
      0133 558
      0133 559 ; Allocate UNIBUS map registers
      0133 560
      0133 561 20$: ASSUME IRPSW_BOFF+2 EQ IRPSW_BCNT
      0133 562 ASSUME UCB$$_BOFF+2 EQ UCB$$_BCNT
7C A5 30 A3 DO 0133 563 MOVL IRPSW_BOFF(R3),UCB$$_BOFF(R5) ; Set buffer offset and count
78 A5 2C A3 DO 0138 564 MOVL IRPSL_SVAPTE(R3),UCB$$_SVAPTE(R5) ; Set buffer PTE address
      01 013D 565 BISW #UCB$$_XM_FORK_XMT,- ; Assume we will have to wait
      68 A5 013F 566 UCB$$_DEVSTS(R5) ; ..for fork block
0000014F'EF 9F 0141 567 PUSHAB 30$ ; Push address of fork process
00000000'GF 17 0147 568 JMP G^IOC$REQMAPREG ; Request map registers
      014D 569
      014D 570 ; The following code may be executed as a fork process, therefore
      014D 571 ; we must provide for a timeout service routine address.
      014D 572
      014D 573
      014D 574 30$: .WORD TIMEOUT- ; Offset to timeout routine
      0151 575 BICW #UCB$$_XM_FORK_XMT,- ; Fork block is no longer in use
      0153 576 BBS #XMSV_STS ACTIVE,- ; Br if still active
      0155 577 UCB$$_DEVDEPEND(R5),40$
      0158 578 RELMPR ; Else, release the map registers
50 2C 3C 015E 579 MOVZWL #SS$ ABORT,R0 ; Return request in error
      0B0C 31 0161 580 BRW IO_DONE ; Complete the I/O request
      0164 581
      57 DD 0164 582 40$: PUSHL R7 ; Save R7
```



```
57 24 A5 D0 0166 583      MOVL    UCBSL_CRB(R5),R7      ; Get CRB address
                                016A 584      ASSUME    VEC$W_MAPREG+2 EQ VEC$B_NUMREG
                                016A 585      ASSUME    VEC$B_NUMREG+1 EQ VEC$B_DATAPATH
                                016A 586      MOVL    CRBSL_INTD+VEC$W_MAPREG(R7),- ; Save mapping info
00EC C544                                016D 587      UCBSL_XM_XMT_MAP(R5)[R4]
                                0171 588      ;
                                0171 589      ; Map the buffer
                                0171 590      ;
                                0171 591      SETBIT   R4,UCBSB_XM_XMT_MAP(R5)      ; Set mapping slot in use flag
3C A3 54 90 0177 592      MOVB    R4,IRPSL_MEDIA+4(R3)      ; Save mapping slot number used
                                017B 593      ASSUME    IRPSW_BOFF+2 EQ IRPSW_BCNT
38 A3 30 A3 D0 017B 594      MOVL    IRPSW_BOFF(R3),IRPSL_MEDIA(R3)      ; Move byte offset and size
                                0180 595      INSV     CRBSL_INTD+VEC$W_MAPREG(R7),- ; Insert BA9-BA15
                                0183 596      #9,#7,IRPSL_MEDIA(R3)
50 38 A3 07 09 EF 0187 597      EXTZV  #7,#2,CRBSL_INTD+VEC$W_MAPREG(R7),R0 ; Get BA16-BA17
38 A3 02 1E 50 F0 018D 598      INSV     R0,#30,#2,IRPSL_MEDIA(R3)      ; Insert BA16-BA17
00000000'GF 16 0193 599      JSB     G^IOC$LOADUBAMAPA      ; Load map registers
                                0199 600      ;
                                0199 601      ; Request and load the port with the buffer address and size, and return.
                                0199 602      ;
57 8ED0 0199 603      POPL     R7      ; Restore R7
07E1 30 019C 604      DSBINT   UCBSB_DIPL(R5)      ; Synch access to device
                                01A3 605      BSBW     LOAD_PORT      ; Load port
                                01A6 606      ENBINT   ; Restore IPL
                                05 01A9 607      RSB      ; Return to caller to await completion
                                01AA 608
```



```
01AA 610 .SBTTL RCVFDT - Receive I/O FDT routine
01AA 611 :++
01AA 612 : RCVFDT - Receive I/O FDT routine
01AA 613 :
01AA 614 : Functional description:
01AA 615 :
01AA 616 : This routine is called by the SYS$QIO service to dispatch a READ I/O
01AA 617 : request.
01AA 618 :
01AA 619 : The QIO parameters for READs are:
01AA 620 :
01AA 621 :     P1 = address of the buffer
01AA 622 :     P2 = size of the buffer
01AA 623 :     P3-P6 = (unused)
01AA 624 :
01AA 625 : The specified buffer is checked for accessibility. The buffer address and
01AA 626 : count are saved in the packet. Then IPL is set to device fork IPL and if
01AA 627 : a message is available the operation is completed. Otherwise the packet
01AA 628 : is queued onto the waiting receive list. The mailbox notified bit is cleared.
01AA 629 :
01AA 630 : For requests specifying IOSM_NOW, the I/O is completed with status of
01AA 631 : SSS_ENDOFFILE if no message is available when the test is made.
01AA 632 :
01AA 633 : For requests specifying IOSM_DSABLMBX the attention mailbox is disabled.
01AA 634 :
01AA 635 : Inputs:
01AA 636 :
01AA 637 :     R3 = I/O packet address
01AA 638 :     R4 = PCB address
01AA 639 :     R5 = UCB address
01AA 640 :     R6 = CCB address
01AA 641 :     R7 = Function code
01AA 642 :     AP = Address of first I/O request parameter
01AA 643 :
01AA 644 : Outputs:
01AA 645 :
01AA 646 :     R0 = Status of the receive request
01AA 647 :
01AA 648 :     R3-R7 preserved.
01AA 649 :--
01AA 650 RCVFDT:
01AA 651 MOVZWL S^#SS$ BADPARAM,R0 ; Receive function routine
01AA 652 MOVZWL P2(AP),R1 ; Assume illegal size
01AA 653 BEQL 10$ ; Get size
01AA 654 MOVL P1(AP),R0 ; Br if none specified
01AA 655 MOVL R0,IRP$L MEDIA(R3) ; Get buffer address
01AA 656 CLRW IRP$W BOFF(R3) ; Save address
01AA 657 JSB G^EXE$READCHK ; No quota to return during completion
01AA 658 ; Check buffer accessibility
01AA 659 ; (no return on no access)
01AA 660 SETIPL UCBS$B FIPL(R5) ; Synchronize access to the UCB
01AA 661 MOVZWL #SS$ DEVOFFLINE,R0 ; Assume device not active
01AA 662 BBC #XMSV STS ACTIVE,- ; Br if not active - abort I/O
01AA 663 UCBS$L DEVDEPEND(R5),10$ ;
01AA 664 BBC #IOSV DSABLMBX,- ; Br if not disabling mailbox
01AA 665 IRP$W FUNC(R3),5$ ;
01AA 666 BICW #XMSM CHR_MBX,UCBS$L DEVDEPEND(R5) ; Else, disable mailbox
01AA 667 BSBB RCV_START ; Start receive operation
```

50	14	3C	01AA	651
51	04 AC	3C	01AD	652
	2F	13	01B1	653
50	6C	D0	01B3	654
38 A3	50	D0	01B6	655
30 A3		B4	01BA	656
00000000	'GF	16	01BD	657
			01C3	658
			01C3	659
50	0084 8F	3C	01C7	660
	0B	E1	01CC	661
11 44	A5		01CE	662
	0A	E1	01D1	663
04 20	A3		01D3	664
44 A5	10	AA	01D6	665
	09	10	01DA	666


```
00000000'GF 17 01DC 667 JMP G^EXESQIORETURN ; Return to await completion
                01E2 668
                FF23 31 01E2 669 10$: BRW ABORTIO ; Abort the I/O request
                01E5 670 ;
                01E5 671 ; Start receive operation.
                01E5 672 ;
                01E5 673 RCV_START: ; Start receive operation
68 A5 0800 8F AA 01E5 674 BICW #UCBSM_XM_NOTIF,UCBSW_DEVSTS(R5) ; Clear notified status
                01EB 675 ;
                01EB 676 ; Check for message available and complete receive if it is
                01EB 677 ;
52 00C8 D5 0F 01EB 678 REMQUE @UCBSQ_XM_RCV_MSG(R5),R2 ; Dequeue a received message
                03 1D 01F0 679 BVS 15$ ; Br if none
                OA43 31 01F2 680 BRW FINISH_RCV_IO ; Complete the I/O and exit
                01F5 681 ;
                01F5 682 ; Queue the request for future message arrival unless IOSM_NOW specified.
                01F5 683 ;
06 20 A3 06 E0 01F5 684 15$: BBS #IOSV_NOW,IRPSW_FUNC(R3),20$ ; Br if read NOW
009C D5 63 0E 01FA 685 INSQUE (R3),@UCBSQ_XM_RCV_REQ+4(R5) ; Queue the I/O packet
                05 01FF 686 RSB ;
                0200 687
50 0870 8F 3C 0200 688 20$: MOVZWL #SS$_ENDOFFILE,R0 ; Set no message status
                OA68 31 0205 689 BRW IO_DONE ; Complete the I/O and exit
                0208 690
                0208 691
```



```
0208 693 .SBTTL ALTFDT - Alternate Transmit/Receive I/O routine
0208 694 :++
0208 695 : ALTFDT - Alternate Transmit/Receive dispatch routine
0208 696 :
0208 697 : Functional description:
0208 698 :
0208 699 : This routine is called by the other drivers to pass an "internal" I/O
0208 700 : request to the driver. "Internal" IRP's are not built via $QIO.
0208 701 : The action here is to setup the IRP fields as if the packet had been
0208 702 : processed by the FDT routines.
0208 703 :
0208 704 : In this driver, the alternate entry point is called by the DECnet
0208 705 : Transport layer driver.
0208 706 :
0208 707 : Inputs:
0208 708 :
0208 709 :     R3 = I/O packet address
0208 710 :     R5 = UCB address
0208 711 :
0208 712 :     All pertinent fields of the IRP are assumed to be valid.
0208 713 :
0208 714 :     IPL = FIPL
0208 715 :
0208 716 : Outputs:
0208 717 :
0208 718 :     R0 = Success
0208 719 :
0208 720 :     R3 and R5 preserved.
0208 721 :--
0208 722 ALTFDT:
0208 723 MOVZWL #SS$ DEVOFFLINE,R0 ; Alternate FDT routine
0208 724 BBS #XMSV_STS_ACTIVE,- ; Assume device not active
0208 725 UCB$ DEVDEPEND(R5),5$ ; Br if active
0208 726 BRW IO_DONE ; Post the I/O request in error
0208 727
0208 728 5$: BBS #IRPSV_FUNC,- ; Br if receive function
0208 729 IRPSW_STS(R3),10$ ;
0208 730 BSBW XMT_START ; Initiate the transmit
0208 731 BRB 20$ ;
0208 732
0208 733 10$: MOVL IRP$L_SVAPTE(R3),R2 ; Get address of input buffer
0208 734 BEQL 15$ ; Br if none
0208 735 BSBW ADDRCLIST ; Add it to the receive list
0208 736 CLRL IRP$L_SVAPTE(R3) ; Buffer now used
0208 737 15$: BSBB RCV_START ; Initiate the receive
0208 738
0208 739 20$: MOVZWL S^#SS$_NORMAL,R0 ; Always return success
0208 740 RSB ;
0208 741
0208 742
```

50 0084 8F 3C 0208 723
03 44 A5 E0 020D 724
0A5B 31 020F 725
01 E0 0212 726
05 2A A3 E0 0215 727
FEF1 30 0217 728
OE 11 021A 729
52 2C A3 D0 021D 730
06 13 021F 731
06A6 30 0221 732
2C A3 D4 0223 733
B8 10 0225 734
50 01 3C 0228 735
05 05 022B 736
0230 737
0231 738
0231 739


```
0231 744 .SBTTL SETMODEFDT - Set mode I/O operation FDT dispatch routine
0231 745 :++
0231 746 : SETMODEFDT - Set mode FDT processing
0231 747 :
0231 748 : Functional description:
0231 749 :
0231 750 : This routine is called by the SYSSQIO service to dispatch a SETMODE/SETCHAR
0231 751 : I/O request.
0231 752 :
0231 753 : The QIO parameters for SETMODE or SETCHAR are:
0231 754 :
0231 755 :     P1 = address of 8 byte characteristics buffer
0231 756 :     P2 = (unused)
0231 757 :     P3 = number of receive buffers to pre-allocate (IOSM_STARTUP only)
0231 758 :     P4-P6 = (unused)
0231 759 :
0231 760 : No modifier -
0231 761 :
0231 762 :     This function is done in the STARTIO routine. Control is passed to
0231 763 :     EXE$SETMODE to validate the new mode buffer and queue the packet.
0231 764 :
0231 765 : IOSM_CTRL -
0231 766 :
0231 767 :     Perform this function on the LINE rather than the circuit. The only
0231 768 :     extra action that is done, is that on a STARTUP request the modem
0231 769 :     is enabled via a master clear to the DMC. This will re-enable the
0231 770 :     DTR signal to the modem. On a SHUTDOWN request, the DTR signal is
0231 771 :     inhibited. The STARTUP or SHUTDOWN bit is then cleared and the I/O
0231 772 :     request is processed as a regular request for the CIRCUIT.
0231 773 :
0231 774 : IOSM_STARTUP -
0231 775 :
0231 776 :     This function starts the unit and sets the mode.
0231 777 :     The action here is to pick up the user buffered i/o quota
0231 778 :     and allocate the base table. The base table address is saved in
0231 779 :     IRPSL_SVAPTE. The quota is taken from the user is in IRPSW_BOFF.
0231 780 :     This value will be the IOSB+2 value at I/O done. This function is
0231 781 :     complete when the base table has been given to the unit. The mailbox
0231 782 :     is enabled and a receive is started. This function is done partially
0231 783 :     here and the remainder is done in STARTIO.
0231 784 :
0231 785 : IOSM_SHUTDOWN -
0231 786 :
0231 787 :     This function shuts down the unit and optionally resets the mode.
0231 788 :     A cancel I/O is preformed, all outstanding I/O is completed, the base
0231 789 :     table and message blocks are all returned and the unit is left in an
0231 790 :     idle state. This function cannot be done here and the FDT processing is
0231 791 :     that of all setmode operations.
0231 792 :
0231 793 : IOSM_ATTNAST -
0231 794 :
0231 795 :     This function sets up a AST to be delivered on one of the following
0231 796 :     conditions:
0231 797 :
0231 798 :         Fatal error that caused shutdown.
0231 799 :         Message available to be received.
0231 800 :
```



```
0231 801 :
0231 802 : Inputs:
0231 803 :
0231 804 : R3 = I/O packet address
0231 805 : R4 = PCB address
0231 806 : R5 = UCB address
0231 807 : R6 = CCB address
0231 808 : R7 = Function code
0231 809 : AP = Address of first I/O request parameter
0231 810 :
0231 811 : Outputs:
0231 812 :
0231 813 : R0 = Status of setmode request
0231 814 :
0231 815 : R3-R5 preserved.
0231 816 :--
0231 817 SETMODEFDT: : Set mode FDT processing
0231 818 CLRL IRPSL_SVAPTE(R3) : Set no buffer
0231 819 MOVW IRPSW_FUNC(R3),R7 : Get entire function code
0231 820 BBC #IOSV_CTRL,R7,5$ : Br if not a LINE request
0231 821 :
0231 822 : LINE request
0231 823 :
0231 824 BSBW SETMODEFDT_LINE : Process a LINE request
0231 825 BLBS R0,10$ : Br if request is complete
0231 826 :
0231 827 5$: BBC #IOSV_ATTNAST,R7,20$ : Br if not AST request
0231 828 :
0231 829 : Attention AST request
0231 830 :
0231 831 MOVAB UCB$X_M AST(R5),R7 : Set address of AST block listhead
0231 832 JSB G^COM$SETATTNAST : Create AST block
0231 833 DSBINT UCB$B_FIPL(R5) : Synch access to UCB
0231 834 CLRL R4 : Set Mailbox msg
0231 835 BBCC #UCB$V_XM LOSTERR,- : Br unless unreported fatal errors
0231 836 UCB$W_DEVSTS(R5),7$ :
0231 837 MOVZBL #MSG$X_M_SHUTDN,R4 : Set message code
0231 838 BRB 8$ :
0231 839 7$: BBC #UCB$V_XM INITED,- : Br if device not initialized
0231 840 UCB$W_DEVSTS(R5),10$ :
0231 841 MOVAB UCB$Q_XM_RCV_MSG(R5),R1 : Get address received message queue
0231 842 CMPL R1,(RT) : Any messages in queue?
0231 843 BEQL 10$ : Br if no - nothing to report yet
0231 844 8$: PUSHL R3 : Save I/O packet address
0231 845 BSBW POKE_USER : Deliver the AST immediately
0231 846 POPL R3 : Restore register
0231 847 10$: MOVL UCB$L_DEVDEPEND(R5),R1 : Get device characteristics
0231 848 JMP G^EXE$FINISHIO : Complete the I/O
0231 849 :
0231 850 : Set mode, startup, or shutdown request. Get the characteristics buffer.
0231 851 :
0231 852 20$: CLRL IRPSL_MEDIA(R3) : Reset mode data buffer
0231 853 PUSHL R3 : Save I/O packet address
0231 854 MOVL P1(AP),R2 : Get address of new characteristics
0231 855 BEQL 30$ : Br if none specified
0231 856 MOVZWL S^#SS$ ACCVIO,R0 : Assume no access
0231 857 IFNORD #8,(R2),45$ : Br if no access to buffer
```

57 2C A3 D4 0231 818
20 A3 B0 0231 819
06 57 09 E1 0231 820
00E2 30 0231 824
3A 50 E8 0231 825
40 57 08 E1 0231 827
57 0114 C5 9E 0231 831
00000000'GF 16 0231 832
54 D4 0231 833
0C E5 0231 834
06 68 A5 0231 835
54 00'8F 9A 0231 836
OF 11 0231 837
03 E1 0231 839
12 68 A5 0231 840
51 00C8 C5 9E 0231 841
61 51 D1 0231 842
08 13 0231 843
53 DD 0231 844
0A41 30 0231 845
53 8ED0 0231 846
51 44 A5 D0 0231 847
00000000'GF 17 0231 848
38 A3 7C 0231 852
53 DD 0231 853
52 6C D0 0231 854
11 13 0231 855
50 0C 3C 0231 856
0293 857


```
38 A3 62 7D 0299 858      MOVQ      (R2),IRP$L_MEDIA(R3)      ; Save new characteristics in packet
38 A3 01 90 029D 859      MOVQB      #1,IRP$L_MEDIA(R3)      ; Mark it "valid"
07 57 06 E0 02A1 860 30$: BBS          #IOSV_STARTUP,R7,50$    ; Br if startup function
53 8ED0 02A5 861      POPL          R3                    ; Restore packet address
6B 11 02A8 862      BRB          90$                     ; Queue the packet
6F 11 02AA 863 45$: BRB          100$                     ;
02AC 864      ;
02AC 865      ; Startup request - check caller's quota and allocate the basetable.
02AC 866      ;
51 08 AC 9A 02AC 867 50$: MOVZBL     P3(AP),R1              ; Get number of receives to preallocate
52 04 D5 12 02B0 868      TSTL          R2                ; Any characteristics specified?
52 40 A5 9E 02B4 869      BNEQ          55$                ; Br if yes
52 02 A2 3C 02B8 870      MOVAB      UCBSB_DEVCLASS(R5),R2    ; Else, set addr to current ones
52 50 14 3C 02BC 871 55$: MOVZWL     2(R2),R2              ; Get receive buffer size
51 52 C4 02BF 872      MOVZWL     S^#SS$_BADPARAM,R0        ; Assume bad parameters
51 57 13 02C2 873      MULL          R2,R1                ; Compute total needed for buffers
0100 8F A0 02C4 874      BEQL          100$                ; Br if somehow in error
57 51 3C 02C9 875      ADDW          #BASETAB_SIZE,R1        ; Add size of base table
57 51 D1 02CC 876      MOVZWL     R1,R7                  ; Copy quota
4A 12 02CF 877      CMPL          R1,R7                  ; Overflow?
00000000'GF 16 02D1 878      BNEQ          100$                ; Br if in error
41 50 E9 02D7 879      JSB          G^EXES$BUFQUOPRC        ; Check caller's quota
51 010C 8F 3C 02DA 880      BLBC          R0,100$            ; Br if error
00000000'GF 16 02DF 881      MOVZWL     #BASETAB_SIZE+BAS_C_HEADER,R1 ; Set size of basetable + header
33 50 E9 02E5 882      JSB          G^EXES$ALOCBUF          ; Allocate the table
53 8ED0 02E8 883      BLBC          R0,100$            ; Return if error
30 A3 57 B0 02EB 884      POPL          R3                    ; Restore I/O packet address
57 57 3C 02EF 885      MOVW          R7,IRP$W_BOFF(R3)      ; Save quota in packet
50 0080 C4 D0 02F2 886      MOVZWL     R7,R7                ; Convert to longword
20 A0 57 C2 02F7 887      MOVL          PCB$JIB(R4),R0      ; Get job info block address
24 A0 57 C2 02FB 888      SUBL          R7,JIB$J_BYTCNT(R0)    ; Adjust byte count quota
2C A3 52 D0 02FF 889      SUBL          R7,JIB$J_BYTLM(R0)    ; ..and byte limit quota
08 A2 51 D0 0303 890      MOVL          R2,IRP$S_SVAPTE(R3)  ; Save base table data address
38 BB 0307 891      MOVL          R1,BAS_W_SIZE(R2)        ; Save size of base table
00 0C A2 00 2C 0309 892      PUSHR          #^M<R3,R4,R5>      ; Save registers
OC A2 00F4 8F 38 BA 030E 893      MOVCS          #0,BAS_T_DATA(R2),#0,- ; Zero the base table
00000000'GF 17 0313 894      #BASETAB_SIZE-BAS_T_DATA,BAS_T_DATA(R2) ;
38 0315 895 90$: POPR          #^M<R3,R4,R5>      ; Restore registers
031B 896      JMP          G^EXES$QIODRVPKT            ; Queue the I/O packet
031B 897      ;
031B 898      ; Setmode/start error
031B 899      ;
53 8ED0 031B 900 100$: POPL          R3                    ; Restore I/O packet address
FDE7 31 031E 901      BRW          ABORTIO                ; Abort the I/O request
0321 902
```



```
0321 904 .SBTTL SETMODEFDT_LINE - Set mode I/O operation FDT routine for LINE
0321 905 :++
0321 906 : SETMODEFDT_LINE - Set mode FDT processing for DMC LINE
0321 907 :
0321 908 : Functional description:
0321 909 :
0321 910 : This routine is called when normal SETMODE FDT processing has detected that
0321 911 : the I/O request is on the line.
0321 912 :
0321 913 : QIO parameters are the same as for regular SETMODE.
0321 914 :
0321 915 : Modifiers:
0321 916 :
0321 917 : IOSM_STARTUP -
0321 918 :
0321 919 : This function forces the DMC/DMR to be master cleared to re-enable
0321 920 : the DTR modem signal.
0321 921 :
0321 922 : IOSM_SHUTDOWN -
0321 923 :
0321 924 : This function shuts down the unit's modem, by calling a routine to
0321 925 : disable the DTR signal to the modem.
0321 926 :
0321 927 : Inputs:
0321 928 :
0321 929 : R3 = I/O packet address
0321 930 : R4 = PCB address
0321 931 : R5 = UCB address
0321 932 : R6 = CCB address
0321 933 : R7 = Function code
0321 934 : AP = Address of first I/O request parameter
0321 935 :
0321 936 : IPL = IPL$_ASTDEL
0321 937 :
0321 938 : Outputs:
0321 939 :
0321 940 : R0 = LBC, if we can continue, else all done with request
0321 941 : R1 is destroyed, all other registers are preserved
0321 942 :
0321 943 :--
0321 944 SETMODEFDT_LINE:
0321 945 MOVZBL #1,R0 ; Set mode FDT processing for DMC LINE
0321 946 BBS #UCB$V_XM_INITED,- ; Assume we can't continue
0321 947 UCB$W_DEVSTS(R5),10$ ; Br if device initialized
0321 948 ; ignore request, circuit must be
0321 949 ; off before playing with modem.
0321 950 BBCC #IOSV_STARTUP,R7,20$ ; Br if not startup function
0321 951 :
0321 952 : STARTUP LINE request, enable DTR
0321 953 :
0321 954 MOVL UCB$$_CRB(R5),R1 ; Get CRB address
0321 955 ASSUME IDB$$_CSR EQ 0
0321 956 MOVL @CRB$C_INTD+VEC$_IDB(R1),R1 ; Get CSR address
0321 957 MOVW #XM_I_M_MCLR,(R1) ; Master clear controller, resets DTR
0321 958 CLRL R0 ; Allow this function to continue
0321 959 BICW #IOSM_STARTUP!IOSM_SHUTDOWN!- ; Clear out all processed flags
0321 960 IOSM_CTRL,IRP$W_FUNC(R3) ;
0321 961 RSB
```

50	01	9A	0321	945	MOVZBL	#1,R0		
	03	E0	0324	946	BBS	#UCB\$V_XM_INITED,-		
13	68	A5	0326	947		UCB\$W_DEVSTS(R5),10\$		
			0329	948				
16	57	06	E5	0329	949	BBCC	#IOSV_STARTUP,R7,20\$	
			032D	950	:			
			032D	951	:			
			032D	952	:			
51	24	A5	D0	032D	953	MOVL	UCB\$\$_CRB(R5),R1	; Get CRB address
			0331	954	ASSUME	IDB\$\$_CSR EQ 0		
51	2C	B1	D0	0331	955	MOVL	@CRB\$C_INTD+VEC\$_IDB(R1),R1	; Get CSR address
61	4000	8F	B0	0335	956	MOVW	#XM_I_M_MCLR,(R1)	; Master clear controller, resets DTR
		50	D4	033A	957	CLRL	R0	; Allow this function to continue
20	A3	02C0	8F	AA	033C	958	10\$: BICW	#IOSM_STARTUP!IOSM_SHUTDOWN!-
					0342	959		; Clear out all processed flags
			05	0342	960	RSB		


```

F5 57 07 E1 0343 961
0343 962 20$: BBC #IOSV_SHUTDOWN,R7,10$ ; Br if not shutdown function, stop
0347 963
0347 964
0347 965
0347 966 BSBW DISABLE_MODEM ; Disable the modem DTR line
55 DD 034A 967 PUSH R5 ; Save UCB address
034C 968 ASSUME IRP$ ARB+4+TQESC LENGTH LE IRP$C_LENGTH
55 53 00000094 8F C1 034C 969 ADDL3 #IRP$C_LENGTH-TQESC_LENGTH,R3,R5 ; Use end of IRP as TQE
0A A5 0F 90 0354 970 MOV B^30$,TQESC_LENGTH,R3 ; Set structure type
OC A5 96 AF 9E 0358 971 MOVAB B^30$,TQESC_LENGTH,R3 ; Set wakeup routine address
0B A5 01 90 035D 972 MOV B^30$,TQESC_LENGTH,R3 ; Set the TQE request type
10 A5 53 D0 0361 973 MOVL R3,TQESC_LENGTH,R3 ; Save IRP address in TQE
0365 974 DSBINT #IPL$_TIMER ; Raise IPL
50 00000000 000F4240 8F 7D 036B 975 MOVQ #SHUT-TIME,R0 ; Calculate the delta time
50 00000000 GF C0 0376 976 ADDL G^EXESGQ_SYSTIME,R0 ; ...
51 00000004 GF D8 037D 977 ADWC G^EXESGQ_SYSTIME+4,R1 ; ...
00000000 GF 16 0384 978 JSB G^EXESINSTIMQ ; Insert TQE on timer queue
038A 979 ENBINT ; Restore IPL
55 BED0 038D 980 POPL R5 ; Restore UCB address
00000000 GF 17 0390 981 JMP G^EXESQIORETURN ; Wait for the TQE to complete request
0396 982
0396 983 : TQE wakeup routine
0396 984
0396 985 R3 = IRP address
0396 986 R5 = TQE address at end of IRP
0396 987
0396 988 IPL = IPL$_TIMER
0396 989
50 01 9A 0396 990 30$: MOVZBL #SS$_NORMAL,R0 ; Return success
55 DD 0399 991 PUSH R5 ; Save TQE address
1C A3 D0 039B 992 MOVL IRP$ UCB(R3),R5 ; Copy UCB address to R5
0BCE 30 039F 993 BSBW IO_DONE ; Complete the I/O request
55 BED0 03A2 994 POPL R5 ; Restore TQE address
05 03A5 995 RSB ; Return to caller
03A6 996
```



```
03A6 998 .SBTTL SENSEMODE - Sense mode I/O operation FDT
03A6 999 :++
03A6 1000 : SENSEMODE - Sense mode FDT processing
03A6 1001 :
03A6 1002 : This routine is called by the SYS$QIO service to dispatch a SENSEMODE
03A6 1003 : SENSECHAR I/O request.
03A6 1004 :
03A6 1005 : The QIO parameters for SENSEMODE are:
03A6 1006 :
03A6 1007 :     P1 = (unused)
03A6 1008 :     P2 = address of descriptor of buffer to receive counters
03A6 1009 :     P3-P6 = (unused)
03A6 1010 :
03A6 1011 : The error counters are returned to the caller in NICE format in the buffer.
03A6 1012 :
03A6 1013 : Inputs:
03A6 1014 :
03A6 1015 :     R3 = I/O packet address
03A6 1016 :     R4 = PCB address
03A6 1017 :     R5 = UCB address
03A6 1018 :     R6 = CCB address
03A6 1019 :     R7 = Function code
03A6 1020 :     AP = Address of first I/O request parameter
03A6 1021 :
03A6 1022 : Outputs:
03A6 1023 :
03A6 1024 :     R0 = Status of diagnose request
03A6 1025 :
03A6 1026 :     R3-R5 preserved.
03A6 1027 :--
03A6 1028 SENSEMODEFDT: ; Sense mode FDT routine
7D 20 A3 08 E1 03A6 1029 BBC #IO$V_RD_COUNT,IRP$W_FUNC(R3),80$ ; Br if not returning counters
03AB 1030 :
03AB 1031 : Check the caller's buffer
03AB 1032 :
50 04 AC D0 03AB 1033 MOVL P2(AP),R0 ; Get user buffer descriptor address
51 60 3C 03AF 1034 IFNORD #8,(R0),10$ ; Check accessibility
50 04 A0 D0 03B5 1035 MOVZWL (R0),R1 ; Get buffer size
00000000'GF 16 03B8 1036 BEQL 10$ ; Br if zero - error
32 51 D1 03BA 1037 MOVL 4(R0),R0 ; Get buffer address
50 14 7D 03BE 1038 JSB G^EXE$READCHK ; Check access to buffer
FD39 31 03C4 1039 ; (no return on no access)
03C4 1040 CMPL R1,#CNT_BUFSIZ ; Is buffer long enough?
50 06 1E 03C7 1041 BGEQU 20$ ; Br if yes
50 14 7D 03C9 1042 10$: MOVQ S^#SS$_BADPARAM,R0 ; Set error status
FD39 31 03CC 1043 BRW ABORTIO ; Abort the I/O request
03CF 1044 :
03CF 1045 : Move driver maintained counters to caller's buffer
03CF 1046 :
57 18 BB 03CF 1047 20$: PUSHR #^M<R3,R4> ; Save registers
50 50 D0 03D1 1048 MOVL R0,R7 ; Set address of caller's buffer
50 04 D0 03D4 1049 MOVL #UCB$C_XM_DRV_CNT,R0 ; Get number of driver counters
51 0120 C5 DE 03D7 1050 MOVAL UCB$C_XM_DRV_CNT(R5),R1 ; Get address of driver counters
52 FC98 CF 9E 03DC 1051 MOVAB CNTTAB,R2 ; Get address of ID table
87 82 B0 03E1 1052 30$: MOVW (R2)+,(R7)+ ; Set counter ID
87 81 D0 03E4 1053 MOVL (R1)+,(R7)+ ; Set counter value
F7 50 F5 03E7 1054 SOBGTR R0,30$ ; Loop through all driver counters
```



```
03EA 1055 :  
03EA 1056 : Move device maintained counters to caller's buffer  
03EA 1057 :  
53 0118 C5 D0 03EA 1058 : MOVL UCB$$_XM_BASSETAB(R5),R3 ; Get address of basetable  
58 D4 03EF 1059 40$: CLRL R8 ; Init bitmask  
59 82 B0 03F1 1060 : MOVW (R2)+,R9 ; Get next counter ID  
30 13 03F4 1061 : BEQL 70$ ; Br if end of table  
87 59 B0 03F6 1062 : MOVW R9,(R7)+ ; Set next ID in buffer  
87 94 03F9 1063 : CLRB (R7)+ ; Clear count  
02 59 0C E1 03FB 1064 : BBC #NMA$V_CNT_MAP,R9,50$ ; Br if not bitmapped  
87 B4 03FF 1065 : CLRW (R7)+ ; Clear bitmap  
0401 1066 :  
54 82 9A 0401 1067 50$: MOVZBL (R2)+,R4 ; Get next basetable counter offset  
E9 13 0404 1068 : BEQL 40$ ; Br if none - no more with this ID  
56 82 9A 0406 1069 : MOVZBL (R2)+,R6 ; Get next UCB counter offset  
0B E1 0409 1070 : BBC #XMS$V_STS_ACTIVE,- ; Br if basetable not active  
F3 44 A5 040B 1071 : UCB$$_DEVDEPEND(R5),50$ ;  
50 6146 6344 81 040E 1072 : ADDB3 (R3)[R4],(R1)[R6],R0 ; Add basetable counter to saved value  
EB 1B 0414 1073 : BLEQU 50$ ; Br if overflow, etc.  
06 59 0C E1 0416 1074 : BBC #NMA$V_CNT_MAP,R9,60$ ; Br if not bitmapped  
58 B6 041A 1075 : INCW R8 ; Increment bitmask  
FD A7 58 A8 041C 1076 : BISW R8,-3(R7) ; Set bitmap  
FF A7 50 80 0420 1077 60$: ADDB R0,-1(R7) ; Add to count  
DB 11 0424 1078 : BRB 50$ ; Loop through all device counters  
0426 1079 :  
18 BA 0426 1080 70$: POPR #^M<R3,R4> ; Restore registers  
0428 1081 :  
0428 1082 : See if counters are to be "cleared". The controller has its own copy of  
0428 1083 : the counters in its RAM, so the basetable copies can't simply be cleared.  
0428 1084 : Instead, a negative of the basetable copies will be saved in the UCB and,  
0428 1085 : later when the counts are requested, the UCB copies will be added to the  
0428 1086 : basetable copies.  
0428 1087 :  
24 20 A3 0A E1 0428 1088 80$: BBC #IOS$V_CLR_COUNT,IRPSW_FUNC(R3),110$ ; Br if not clearing counters  
0120 C5 7C 042D 1089 : CLRL UCB$$_RCVBYTCNT(R5) ; Clear byte counts  
0128 C5 7C 0431 1090 : CLRL UCB$$_RCVMSGCNT(R5) ; Clear message counts  
51 0130 C5 9E 0435 1091 : MOVAB UCB$$_XM_DEVCNT(R5),R1 ; Get address of saved counters  
52 0118 C5 03 C1 043A 1092 : ADDL3 #3,UCB$$_XM_BASSETAB(R5),R2 ; Get address of basetable counters  
59 08 D0 0440 1093 : MOVL #UCB$$_XM_DEVCNT,R9 ; Set number of counters  
81 94 0443 1094 90$: CLRB (R1)+ ; Clear saved counter  
0B E1 0445 1095 : BBC #XMS$V_STS_ACTIVE,- ; Br if basetable not active  
04 44 A5 0447 1096 : UCB$$_DEVDEPEND(R5),100$ ;  
FF A1 82 8E 044A 1097 : MNEGB (R2)+,-1(R1) ; Store negative of basetable counter  
F2 59 F5 044E 1098 100$: SOBGTR R9,90$ ; Loop through counters  
0451 1099 :  
50 32 10 78 0451 1100 110$: ASHL #16,#CNT_BUFSIZ,R0 ; Set returned buffer size  
50 50 01 B0 0455 1101 : MOVW S^#SS$_NORMAL,R0 ; Success return  
00000000*GF 17 0458 1102 : JMP G^EXES$FINISHIOC ; Post the I/O  
045E 1103 :
```



```
045E 1105 .SBTTL STARTIO - Start setmode I/O operation
045E 1106 :++
045E 1107 : STARTIO - Start setmode operation
045E 1108 :
045E 1109 : Functional description:
045E 1110 :
045E 1111 : This routine is entered to process a setmode request. All setmode
045E 1112 : requests are queued to single-stream them.
045E 1113 :
045E 1114 : For all functions a change in the characteristics is done.
045E 1115 :
045E 1116 : For startup, the action is to request and set up the UNIBUS
045E 1117 : map for the base table and receives. This data is saved
045E 1118 : after allocation in the UCB. After this the base table and
045E 1119 : receive buffer addresses are passed to the device, thus starting
045E 1120 : the protocol running.
045E 1121 :
045E 1122 : For shutdown, the device is master cleared and all buffers and
045E 1123 : quotas are returned.
045E 1124 :
045E 1125 : Inputs:
045E 1126 :
045E 1127 : R3 = I/O packet address
045E 1128 : R5 = UCB address
045E 1129 :
045E 1130 : Outputs:
045E 1131 :
045E 1132 : R3 and R5 preserved.
045E 1133 :
045E 1134 : I/O request completed.
045E 1135 :--
045E 1136 STARTIO: : Start I/O routine
045E 1137 BBC #IOSV_STARTUP,- : Br if not startup request
0460 1138 IRPSW_FUNC(R3),10$ :
0463 1139 :
0463 1140 : Startup request
0463 1141 :
0463 1142 BBC #XMSV_STS_ACTIVE,- : Br if it is NOT active
0465 1143 UCBSL_DEVDEPEND(R5),5$ :
0468 1144 MOVZWL IRPSL_PID(R3),R0 : Get process index from IRP
046C 1145 MOVL G^SCH$GL_PCBVEC,R1 : Get address of PCB address vector
0473 1146 MOVL (R1)[R0],R0 : Get PCB address
0477 1147 CMPL PCBSL_PID(R0),- : Still same process?
047A 1148 IRPSL_PID(R3) :
047C 1149 BNEQ 3$ : Br if not - forget it
047E 1150 MOVL PCBSL_JIB(R0),R0 : Get JIB address
0483 1151 MOVZWL IRPSW_BOFF(R3),R1 : Convert quota to longword
0487 1152 ADDL R1,JIBSL_BYTCNT(R0) : Return byte count quota
048B 1153 ADDL R1,JIBSL_BYTLM(R0) : ..and byte limit quota
048F 1154 3$: CLRW IRPSW_BOFF(R3) : Reset quota charge
0492 1155 MOVZWL #SS$_DEACTIVE,R0 : Device already started
0497 1156 BRB 40$ : Complete the request
0499 1157 :
0024 31 0499 1158 5$: BRW STARTUP : Start the device
049C 1159 :
049C 1160 : Shutdown request
049C 1161 :
```



```

      07 E1 049C 1162 10$: BBC #IOSV_SHUTDOWN,- ; Br if not shutdown request
50 0F 20 A3 049E 1163      IRPSW_FUNC(R3),20$ ;
      8F 3C 04A1 1164      MOVZWL #SS$ DEVOFFLINE,R0 ; Assume device not started yet
      0B E1 04A6 1165      BBC #XMSV_STS_ACTIVE,- ; Br if not active
      44 A5 04A8 1166      UCB$L_DEVDEPEND(R5),40$ ;
      0B 30 04AB 1167      BSBW SHUTDOWN ; Shutdown the device
      08F7 11 04AE 1168      BRB 30$ ;
      03      04B0 1169      ; Just a change mode request
      04B0 1170      ;
      04B0 1171      ;
      03F3 30 04B0 1172 20$: BSBW CHANGE_MODE ; Change mode and characteristics
      04B3 1173      ;
      50 01 3C 04B3 1174 30$: MOVZWL S^#SS$ NORMAL,R0 ; Set success
51 44 A5 D0 04B6 1175 40$: MOVL UCB$L_DEVDEPEND(R5),R1 ; Set device characteristics
      04BA 1176      REQCOM ; Complete the request
      04C0 1177
```



```
04C0 1179 .SBTTL STARTUP - Start up controller
04C0 1180 :++
04C0 1181 : STARTUP - Start up controller
04C0 1182 :
04C0 1183 : Functional description:
04C0 1184 :
04C0 1185 : This routine starts the controller running. The action is to allocate
04C0 1186 : the map registers for the base table and receives. Once this is done,
04C0 1187 : the unit is master cleared and the base table and mode are set up.
04C0 1188 : The receive buffer list is filled and the receives started.
04C0 1189 :
04C0 1190 :
04C0 1191 : Inputs:
04C0 1192 :
04C0 1193 : R3 = I/O packet address
04C0 1194 : R5 = UCB address
04C0 1195 :
04C0 1196 : IRP$L_MEDIA(R3) = New mode buffer
04C0 1197 : IRP$L_SVAPTE(R3) = Address of allocated base table.
04C0 1198 : IRP$W_BOFF(R3) = Quota taken from caller.
04C0 1199 :
04C0 1200 : Outputs:
04C0 1201 :
04C0 1202 : Device started and I/O request completed.
04C0 1203 :
04C0 1204 : R3,R5 preserved.
04C0 1205 :--
04C0 1206 : STARTUP:
04C0 1207 : INSV #0,#8,#24,UCB$L_DEVDEPEND(R5) ; Startup controller
04C6 1208 : BSBW CHANGE_MODE ; Reset status and error flags
04C9 1209 : ; Set new characteristics
04C9 1210 : Initialize the buffer and I/O request queue heads
04C9 1211 :
04C9 1212 : MOVL #UCB$C_XM_QUEUES,R0 ; Set number of queue heads
04CC 1213 : MOVAB UCB$Q_XM_QUEUES(R5),R2 ; Set address of first head
04D1 1214 10$: MOVAB (R2),(R2)+ ; Set forward link
04D4 1215 : MOVAB -4(R2),(R2)+ ; Set backward link
04D8 1216 : SOBGTR R0,10$ ; Loop through all queue heads
04DB 1217 :
04DB 1218 : Initialize the transmit and receive mapping info vectors.
04DB 1219 :
04DB 1220 : MOVL #MAX_RCV+MAX_XMT,R0 ; Set number receive and transmit slots
04DE 1221 : ASSUME UCB$C_XM_RCV_MAP+<4*MAX_RCV> EQ UCB$L_XM_XMT_MAP
04DE 1222 : MOVAL UCB$L_XM_RCV_MAP(R5),R1 ; Get mapping vector address
04E3 1223 20$: MNEGL #1,(R1)+ ; Indicate no mapping info
04E6 1224 : SOBGTR R0,20$ ; Loop through all mapping slots
04E9 1225 : MOVAB #MAX_RCV,UCB$B_XM_RCV_MAX(R5) ; Set maximum concurrent receives
04EE 1226 : MOVAB #MAX_XMT,UCB$B_XM_XMT_MAX(R5) ; Set maximum concurrent transmits
04F3 1227 : MNEGL #1,UCB$L_XM_BASEMAP(R5) ; Set no mapping for basetable yet
04F8 1228 :
04F8 1229 : SUBW3 #BASETAB_SIZE,- ; Compute quota for receive buffers
04FC 1230 : IRP$W_BOFF(R3),UCB$W_XM_QUOTA(R5)
0501 1231 : MOVZWL UCB$W_XM_QUOTA(R5),R1 ; Get buffer quota as longword
0506 1232 : MOVZWL UCB$W_DEVBUFSIZ(R5),R0 ; Get buffer size as longword
050A 1233 : DIVL R0,R1 ; Compute maximum number of receive
050D 1234 : ; buffers based on quota
050D 1235 : CMPB R1,UCB$B_XM_RCV_MAX(R5) ; Is number less than maximum?
```



```
010A C5 05 1E 0512 1236 BGEQU 30$ ; Br if not - value ok
OC 51 90 0514 1237 MOVW R1,UCBSB_XM_RCV_MAX(R5) ; Else reduce number to quota
A3 D0 0519 1238 30$: MOVW IRPSL_PID(R3),- ; Save starter's process ID
0110 C5 051C 1239 UCB$X_M_PID(R5) ;
051F 1240 ;
051F 1241 ; Save basetable info
051F 1242 ;
54 2C A3 OC C1 051F 1243 ADDL3 #BAS_T_DATA,IRPSL_SVAPTE(R3),R4 ; Get basetable address
0118 C5 54 D0 0524 1244 MOVW R4,UCBSL_XM_BASSETAB(R5) ; Save in UCB
2C A3 D4 0529 1245 CLRL IRPSL_SVAPTE(R3) ; No buffer or quota
30 A3 B4 052C 1246 CLRW IRPSW_BOFF(R3) ; for I/O post
08 A8 052F 1247 B1SW #UCBSM_XM_INITED,- ; Indicate UCB fields now initialized
68 A5 0531 1248 UCB$W_DEVSTS(R5) ; sufficiently so shutdown can cleanup
0533 1249 ;
0533 1250 ; Allocate map registers for receive buffers. The
0533 1251 ; unbuffered datapath (DPO) is used for all I/O's due to the fact that
0533 1252 ; the controller can initiate retransmissions but on the 11/780, the datapath
0533 1253 ; requires purging before it can be reused.
0533 1254 ;
42 A5 B0 0533 1255 MOVW UCB$W_DEVBUFSIZ(R5),- ; Set buffer size
7E A5 0536 1256 UCB$W_BCNT(R5)
7C A5 01FF 8F B0 0538 1257 MOVW #511,UCBSW_BOFF(R5) ; Set worst case byte offset
54 24 A5 D0 053E 1258 MOVW UCB$X_CRB(R5),R4 ; Get CRB address
0542 1259 ASSUME VEC$W_MAPREG+2 EQ VEC$B_NUMREG
0542 1260 ASSUME VEC$B_NUMREG+1 EQ VEC$B_DATAPATH
34 A4 D4 0542 1261 CLRL CRBSL_INTD+VEC$W_MAPREG(R4) ; Clear map register + datapath
00C0 8F BB 0545 1262 PUSHR #*M<R6,R7> ; Save regs
56 00D0 C5 DE 0549 1263 MOVAL UCB$X_XM_RCV_MAP(R5),R6 ; Get mapping slot address
57 010A C5 9A 054E 1264 MOVZBL UCB$B_XM_RCV_MAX(R5),R7 ; Get number of receive slots
00000000 GF 16 0553 1265 40$: JSB G*IOC$ALDUBAMAP ; Allocate a set of map registers
07 50 E9 0559 1266 BLBC R0,50$ ; Br if unavailable
86 34 A4 D0 055C 1267 MOVW CRBSL_INTD+VEC$W_MAPREG(R4),(R6)+ ; Save map info
F0 57 F5 0560 1268 SOBGTR R7,40$ ; Continue until done
0563 1269
00C0 8F BA 0563 1270 50$: POPR #*M<R6,R7> ; Restore regs
18 50 E9 0567 1271 BLBC R0,60$ ; Br if error
056A 1272 ;
056A 1273 ; Map base table
056A 1274 ;
7C A5 FE00 8F AB 056A 1275 BICW3 #*C<VASM_BYTE>,- ; Get basetable byte offset
0118 C5 056E 1276 UCB$X_XM_BASSETAB(R5),UCBSW_BOFF(R5)
7E A5 0100 8F B0 0573 1277 MOVW #BASSETAB_SIZE,UCBSW_BCNT(R5) ; Set basetable size
00000000 GF 16 0579 1278 JSB G*IOC$ALDUBAMAP ; Allocate map registers
08 50 E8 057F 1279 BLBS R0,70$ ; Br if allocated
50 0344 8F 3C 0582 1280 60$: MOVZWL #SS$_INSFMAPREG,R0 ; Set insufficient map registers
02C4 31 0587 1281 BRW START_ERROR ;
058A 1282
34 A4 D0 058A 1283 70$: MOVW CRBSL_INTD+VEC$W_MAPREG(R4),- ; Save basetable mapping info
011C C5 058D 1284 UCB$X_XM_BASMAP(R5)
09 EF 0590 1285 EXTZV S*#VASS_VPN,- ; Get basetable page number
51 0118 C5 15 0592 1286 S*#VASS_VPN,UCBSL_XM_BASSETAB(R5),R1
50 00000000 GF D0 0597 1287 MOVL G*MMGS$C_SPTBASE,R0 ; Get SPT address
78 A5 6041 DE 059E 1288 MOVAL (R0)[R1],UCBSL_SVAPTE(R5) ; Set PTE address
00000000 GF 16 05A3 1289 JSB G*IOC$LOADUBAMAPA ; Load the basetable map registers
34 A4 F0 05A9 1290 ASSUME UCB$W_BOFF+2 EQ UCB$W_BCNT
7C A5 07 09 05A9 1291 CRBSL_INTD+VEC$W_MAPREG(R4),- ; Set BA9-BA15
05AC 1292 #9,#7,UCBSW_BOFF(R5) ;
```



```

7C A5 02 07 EF 05B0 1293 EXTZV #7,#2,- : Get BA16-BA17
50 34 A4 F0 05B3 1294 CRBSL INTD+VECSW MAPREG(R4),R0
1E 50 05B6 1295 INSV R0,#30,#2,UCBSW_BOFF(R5) ; Set BA16-BA17
05B8 1296
05BC 1297 : Master clear the device and notify it of the address of the base table
05BC 1298
54 2C B4 D0 05BC 1299 80$: MOVL @CRBSL_INTD+VECSL_IDB(R4),R4 ; Get CSR address
05C0 1300 DSBINT UCBSB_DIPL(R5) ; Disable device interrupts
03 A4 03 90 05C7 1301 MOVW #DMC_DMR,XM_O_CSR+1(R4) ; Set DMC/DMR test value
64 4000 8F B0 05CB 1302 MOVW #XM_I_M_MCLR,(R4) ; Master clear controller
05D0 1303 TIMEWAIT #15,#XM_I_M_RUN,(R4),W ; Wait for RUN - try 150 usecs
05 50 E9 05F5 1304 BLBC R0,85$ ; Br if device NOT ready
05F8 1305 ENBINT ; Else, re-enable interrupts
20 11 05FB 1306 BRB 95$ ; And continue
05FD 1307
05FD 1308 85$: WFIKPC 90$,#2 ; Else, wait about a second for diagnostics
0607 1309 90$: IOFORK ; Schedule a fork process
64 A5 0040 8F AA 060D 1310 BICW #UCBSM_TIMEOUT,UCBSW_STS(R5) ; Clear timeout status
64 8000 8F B3 0613 1311 BITW #XM_I_M_RUN,(R4) ; Device running?
03 03 12 0618 1312 BNEQ 95$ ; Br if yes
022C 31 061A 1313 BRW START_CTRL_ERROR ; Else, error
OC A5 0B84 CF 9E 061D 1314 95$: MOVAB W^FORK_PROG,UCBSL_FPC(R5) ; Set Fork process PC address
03 A4 03 91 0623 1315 CMPB #DMC_DMR,XM_O_CSR+1(R4) ; Device a DMC11?
03 12 0627 1316 BNEQ 99$ ; Br if not
00B8 31 0629 1317 BRW 120$ ; Else, must be a DMC11
41 A5 02 90 062C 1318 99$: MOVW #DTS_DMR11,UCBSB_DEVTYPE(R5) ; Indicate a DMR11
0630 1319
0630 1320 DMR unit - get interface bits, modem signals and configuration bits
0630 1321
0630 1322 Now, get the interface bits (INTMOD, V.35, RS-232, RS-422)
0630 1323
64 20 A8 0630 1324 BISW #XM_I_M_RQI,(R4) ; Assert RQI
0633 1325 TIMEWAIT #6,#XM_I_M_RDI,(R4),W ; Wait for controller to come ready
17 50 E8 0658 1326 BLBS R0,105$ ; Br if port ready
065B 1327 DSBINT UCBSB_DIPL(R5) ; Else, disable device interrupts
0662 1328 WFIKPC 100$,#2 ; Wait for about 2 seconds
066C 1329 100$: IOFORK ; Create a fork process
51 50 07 A4 90 0672 1330 105$: MOVW XM_UCODE+1(R4),R0 ; Get interface bits
51 51 02 03 EF 0676 1331 EXTZV #3,#2,R0,R1 ; Get interface bits (INTMOD & V.35)
47 A5 51 02 78 067B 1332 ASHL #MOD$V_XM_INTMOD,R1,R1 ; Shift to start of interface bits
51 50 FE 8F 78 067F 1333 MOVW R1,UCBSL_DEVDEPEND+3(R5) ; Save in UCB @ DEVDEPEND+3
51 51 CF 8F 8A 0683 1334 ASHL #MOD$V_XM_RS232-6,R0,R1 ; Shift down next two interface bits
0688 1335 BICB #^C<MOD$M_XM_RS232!- ; Remove extraneous bits
068C 1336 MOD$M_XM_RS422>,R1
47 A5 51 88 068C 1337 BISB R1,UCBSL_DEVDEPEND+3(R5) ; Save in UCB
0690 1338
0690 1339 Now, get the modem signals
0690 1340
0150 C5 04 A4 B0 0690 1341 MOVW XM_PORT(R4),UCBSW_XM_MODSIG(R5) ; Save modem signals
64 B4 0696 1342 CLRW (R4) ; Clear RUN, RDI and RQI bits
0698 1343
0698 1344 Now, check the BSEL1 lockout switch - and get the config bits if okay
0698 1345
64 8000 8F B3 0698 1346 BITW #XM_I_M_RUN,(R4) ; Did we clear RUN?
03 13 069D 1347 BEQL 110$ ; Br if yes - no BSEL1 lockout
0115 31 069F 1348 BRW 150$ ; Else, BSEL1 is locked - skip tests
80 8F 88 06A2 1349 110$: BISB #MOD$M_XM_BSEL1,- ; Indicate BSEL1 is ok
```



```

06 A4 47 A5 06A5 1350
64 2296 8F B0 06A7 1351
64 0300 8F A8 06AD 1352
06B2 1353
51 50 06 A4 B0 06D5 1354
50 02 01 EF 06D9 1355
47 A5 51 88 06DE 1356
7A 11 06DE 1357
06E2 1358
06E4 1359
06E4 1360
06E4 1361
06E4 1362
06E4 1363
64 8000 8F AA 06E4 1364 120$: BICW #XM_I_M_RUN,(R4) ; Clear RUN bit
64 8000 8F B3 06E9 1365 BITW #XM_I_M_RUN,(R4) ; Did we clear it?
03 13 06EE 1366 BEQL 125$ ; Br if YES - BSEL1 is okay
00C4 31 06F0 1367 BRW 150$ ; Else, BSEL1 is locked out
80 8F 90 06F3 1368 125$: ASSUME MOD$V_XM_HIGH EQ 0 ; Else, read rom u-code
47 A5 06F6 1370 MOVW #MOD$M_XM_BSEL1,- ; Indicate BSEL1 is okay
06 A4 814D 8F B0 06F8 1371 UCBSL_DEVDEPEND+3(R5) ; ..and assume Low Speed u-code
64 0300 8F A8 06FE 1372 MOVW #UINST_RROM,XM_UCODE(R4) ; Read the DMC rom
0300 8F AA 0703 1373 BICW #XM_I_M_STEPUP!XM_I_M_ROMI,(R4) ; Step the microprocessor
64 0300 8F AA 0726 1374 WAIT10 #2 ; Wait 20 useconds
64 0400 8F A8 072B 1375 BICW #XM_I_M_ROMI!XM_I_M_STEPUP,(R4) ; Clear maintenance bits
0390 8F B1 0730 1376 BICW #XM_I_M_ROMI,(R4) ; Set ROM0 bit
03 13 0753 1377 WAIT10 #2 ; Wait 20 useconds
47 A5 96 075B 1379 CMPW #LS_UCODE,XM_UCODE(R4) ; Is it low-speed u-code?
64 4000 8F B0 075E 1380 BEQL 130$ ; Br if yes - okay
05 50 E9 075B 1380 ASSUME MOD$M_XM_HIGH EQ 1 ; Else, indicate high-speed u-code
20 11 075E 1381 130$: INCB UCBSL_DEVDEPEND+3(R5) ; Disable device interrupts
64 A5 0040 8F AA 0765 1382 DSBINT UCBSB_DIPL(R5) ; Master clear controller - again!
64 8000 8F B3 076A 1383 MOVW #XM_I_M_MCLR,(R4) ; Wait for RUN - try 150 usecs
0092 31 076A 1383 TIMEWAIT #15,#XM_I_M_RUN,(R4),W ; Br if device NOT ready
0884 CF 9E 078F 1384 BLBC R0,135$ ; Else, re-enable interrupts
0792 1385 ENBINT ; And continue
0795 1386 BRB 150$
0797 1387
0797 1388 135$: WFIKPC 140$,#2 ; Else, wait about a second
64 A5 0040 8F AA 07A1 1389 140$: IOFORK ; Schedule a fork process
64 8000 8F B3 07AD 1391 BICW #UCBSM_TIMEOUT,UCBSW_STS(R5) ; Clear timeout status
03 12 07B2 1392 BITW #XM_I_M_RUN,(R4) ; Device running?
0092 31 07B4 1393 BNEQ 150$ ; Br if yes
0C A5 0884 CF 9E 07B7 1394 150$: BRW START_CTRL_ERROR ; Else, error
07BD 1395 MOVAB W^FORK_PROC,UCBSL_FPC(R5) ; Set Fork process PC address
07BD 1396
07BD 1397 ; Set LOOPBACK mode if enabled
07BD 1398
07BD 1399
05 44 A5 E1 07BD 1399 BBC #XMSV_CHR_LOOPB,- ; Br if not loopback mode
64 0800 8F A8 07BF 1400 UCBSL_DEVDEPEND(R5),180$ ; Else, set loopback flag
50 23 90 07C2 1401 BICW #XM_I_M_LOOPB,(R4) ; Set command for basetable-in
0097 30 07C7 1402 180$: MOVW #XM_I_M_RQI!3,R0 ; Request port
04 A4 7C A5 B0 07CA 1403 BSBW START_REQ_PORT ; Set basetable BA0-BA15
06 A4 7E A5 B0 07CD 1404 MOVW UCBSW_BOFF(R5),XM_PORT(R4) ; Set basetable BA16-BA17
07D2 1405 MOVW UCBSW_BCNT(R5),XM_PORT+2(R4) ; Disable all interrupts
07D7 1406 SETIPL
```



```
64 A5 05 E0 07DA 1407 BBS #UCBSV_POWER,UCBSW_STS(R5),- ; Br if power failed
      6A 07DE 1408 START_CTRL_ERROR ;
64 20 AA 07DF 1409 BICW #XM_I_M_RQI,(R4) ; Release port
      07E2 1410 SETIPL UCBSB_FIPL(R5) ; Restore IPL
      0081 30 07E6 1411 BSBW START_WAIT_PORT ; Wait for controller ready
      07E9 1412 ;
      07E9 1413 ; Set the device mode and enable interrupts
      07E9 1414 ;
50 21 90 07E9 1415 MOVW #XM_I_M_RQI!1,R0 ; Set command for control-in
      76 10 07EC 1416 BSBB START_REQ_PORT ; Request port
      04 A4 B4 07EE 1417 CLRW XM_PORT(R4) ; Clear port (?)
      AB 07F1 1418 BICW3 #^C<<XMSM_CHR_MOP!- ; Set mode bits
      07F2 1419 XMSM_CHR_HDPLX!- ;
      07F2 1420 XMSM_CHR_SLAVE>@8>- ;
06 A4 43 A5 F2FF 8F 07F2 1421 UCBSL_DEVDEPEND-1(R5),XM_PORT+2(R4)
      64 20 8A 07F9 1422 BICB #XM_I_M_RQI,(R4) ; Free port
      07FC 1423 ;
      014C C5 64 B0 07FC 1424 MOVW XM_I_CSR(R4),UCBSL_XM_LSTCSR(R5); Save CSR values
014E C5 02 A4 B0 0801 1425 MOVW XM_O_CSR(R4),UCBSL_XM_LSTCSR+2(R5)
0148 C5 04 A4 B0 0807 1426 MOVW XM_PORT(R4),UCBSL_XM_LSTPRT(R5); Save port values
014A C5 06 A4 B0 080D 1427 MOVW XM_PORT+2(R4),UCBSL_XM_LSTPRT+2(R5)
0C A5 0B84 CF 9E 0813 1428 MOVAB W^FORK_PROC,UCBSL_FPC(R5) ; Set normal fork process
      02 A4 40 8F 90 0819 1429 MOVW #XM_O_M_IEO,XM_O_CSR(R4) ; Enable output interrupts
      02 A4 40 8F 90 081E 1430 MOVW #XM_O_M_IEO,XM_O_CSR(R4) ; (again)
      0823 1431 SETIPL ; Disable all interrupts
      64 A5 05 E0 0826 1432 BBS #UCBSV_POWER,UCBSW_STS(R5),- ; Br if power failed
      1E 082A 1433 START_CTRL_ERROR ;
      0800 8F A8 082B 1434 BISW #XMSM_STS_ACTIVE,- ;
      44 A5 082F 1435 UCBSL_DEVDEPEND(R5) ; Set controller now active
      0831 1436 SETIPL UCBSB_FIPL(R5) ; Restore IPL
      0835 1437 ;
      0835 1438 ; Start receives and complete the request
      0835 1439 ;
      008E 30 0835 1440 BSBW FILLRCVLIST ; Fill receive buffer list
      0100 8F A1 0838 1441 ADDW3 #BASETAB_SIZE,- ; Set quota as bytecount in I/O status
50 010C C5 083C 1442 UCBSW_XM_QUOTA(R5),R0 ;
50 50 10 78 0840 1443 ASHL #16,R0,R0 ; Shift into place
      50 01 B0 0844 1444 MOVW S^SSS_NORMAL,R0 ; Set success
      OD 11 0847 1445 BRB START_COMPLETE ;
      0849 1446 ;
      0849 1447 ; Error during startup - shutdown and complete I/O request
      0849 1448 ;
      0849 1449 START_CTRL_ERROR: ; Controller error during startup
50 0054 8F 3C 0849 1450 MOVZWL #SSS_CTRLERR,R0 ;
      50 DD 084E 1451 START_ERROR: ; Error during startup
      0552 30 084E 1452 PUSHL R0 ; Save failure status
      50 8ED0 0850 1453 BSBW SHUTDOWN ; Shutdown in case partly started
      0853 1454 POPL R0 ; Restore status
      0856 1455 START_COMPLETE: ; Complete startup request
      51 44 A5 D0 0856 1456 MOVL UCBSL_DEVDEPEND(R5),R1 ; Get device dependent longword
      53 58 A5 D0 085A 1457 MOVL UCBSL_IRP(R5),R3 ; Get I/O packet address
      085E 1458 REQCOM ; Complete I/O request
      0864 1459 ;
      0864 1460 ;++
      0864 1461 ; START_REQ_PORT - Startup sequence request port
      0864 1462 ; START_WAIT_PORT - Startup sequence wait for port
      0864 1463 ;
```



```
0864 1464 : Inputs:
0864 1465 :
0864 1466 :      R0 = Command (REQ_PORT only)
0864 1467 :      R4 = CSR address
0864 1468 :      R5 = UCB address
0864 1469 :      00(SP) = Return address
0864 1470 :
0864 1471 : Outputs:
0864 1472 :
0864 1473 :      If unsuccessful, exits to START_CTRL_ERROR.
0864 1474 : --
0864 1475 START_REQ_PORT:
0864 1476      BISB R0,(R4) ; Set function and wait
0864 1477      BISB R0,(R4) ; Set command in CSR
0864 1478 START_WAIT_PORT: ; (again)
0864 1479      SETIPL UCB$B_FIPL(R5) ; Wait for controller ready
0864 1480      TIMEDWAIT TIME=#25,- ; Lower IPL
0864 1481      INS1=<BICB3 #^C<XM_I_M_RDI!XM_I_M_RQI>,(R4),R2>,- ; Get flags
0864 1482      INS2=<BEQL 20$>,- ; Br if both clear -done
0864 1483      INS3=<CMPB #XM_I_M_RDI!XM_I_M_RQI,R2>,- ; Check if both set
0864 1484      INS4=<BEQL 20$>,- ; Br if both set - done
0864 1485      DONELBL=20$
0864 1486      BLBS R0,40$ ; Br if success
0864 1487      ADDL #4,SP ; Else, Pop return address
0864 1488      BRB START_CTRL_ERROR ; Exit
0864 1489
0864 1490 40$: SETIPL UCB$B_DIPL(R5) ; Raise IPL again
0864 1491      RSB ;
0864 1492
```

64 50 88
64 50 88
05 50 E8
5E 04 C0
A8 11
05


```
08A6 1494      .SBTTL  CHANGE_MODE - Change mode and characteristics
08A6 1495      :++
08A6 1496      : CHANGE_MODE - Change mode and characteristics
08A6 1497      :
08A6 1498      : Functional description:
08A6 1499      :
08A6 1500      : This routine is entered for changing the mode and characteristics on an idle
08A6 1501      : or active unit:
08A6 1502      :
08A6 1503      : Inputs:
08A6 1504      :
08A6 1505      :     R3 = I/O packet address
08A6 1506      :     R5 = UCB address
08A6 1507      :
08A6 1508      :     IRPSL_MEDIA(R3) = Receive buffer size
08A6 1509      :     IRPSL_MEDIA+4(R3) = New device dependent characteristics
08A6 1510      :
08A6 1511      : The device dependent longword is defined by $XMDEF:
08A6 1512      :
08A6 1513      : +-----+-----+-----+-----+
08A6 1514      : | not used | error status | status | characteristics |
08A6 1515      : +-----+-----+-----+-----+
08A6 1516      :
08A6 1517      : Outputs:
08A6 1518      :
08A6 1519      :     UCBSW_DEVBUFFSIZ(R5) = Receive buffer size
08A6 1520      :     UCBSL_DEVDEPEND(R5) = Device dependent characteristics
08A6 1521      : --
08A6 1522      : CHANGE_MODE:
38 A3 97 08A6 1523      : DECB  IRPSL_MEDIA(R3)      : Valid data buffer?
      1A 12 08A9 1524      : BNEQ 10$      : Br if not
3A A3 B0 08AB 1525      : MOVW IRPSL_MEDIA+2(R3),- : Set new buffer size
42 A5      08AE 1526      : UCBSW_DEVBUFFSIZ(R5)
FFFFF7FF 8F CA 08B0 1527      : BICL #^C<XMSM STS ACTIVE>,- : Clear all but active flag
44 A5      08B6 1528      : UCBSL_DEVDEPEND(R5)
00000800 8F CA 08B8 1529      : BICL #<XMSM STS ACTIVE>,- : Clear active flag
3C A3      08BE 1530      : IRPSL_MEDIA+4(R3)
3C A3 C8 08C0 1531      : BISL IRPSL_MEDIA+4(R3),- : Set new characteristics
44 A5      08C3 1532      : UCBSL_DEVDEPEND(R5)
      05 08C5 1533 10$: RSB
      08C6 1534
```



```
08C6 1536 .SBTTL FILLRCVLIST - Fill receive buffer list
08C6 1537 :++
08C6 1538 : FILLRCVLIST - Fill receive buffer list
08C6 1539 : ADDRCLVLIST - Add a buffer to receive list
08C6 1540 :
08C6 1541 : Functional description:
08C6 1542 :
08C6 1543 : This routine fills the receive buffer free list up to the quota specified
08C6 1544 : at device startup.
08C6 1545 :
08C6 1546 : Inputs:
08C6 1547 :
08C6 1548 :     R2 = Buffer address (ADDRCLVLIST only)
08C6 1549 :     R5 = UCB address
08C6 1550 :
08C6 1551 :     IPL = FIPL
08C6 1552 :
08C6 1553 : Outputs:
08C6 1554 :
08C6 1555 :     R5 = UCB address
08C6 1556 :     R1,R2,R4 destroyed.
08C6 1557 :--
08C6 1558 FILLRCVLIST:
08C6 1559 CLRL R2
08C6 1560 BBS #XMSV_STS_ACTIVE,-
08CA 1561 UCB$L_DEVDEPEND(R5),ADDRCLVLIST
08CD 1562 RSB
08CE 1563 ADDRCLVLIST:
08CE 1564 PUSHR #M<R0,R3>
08D0 1565 5$: CMPW UCB$W_DEVBUFSIZ(R5),-
08D3 1566 UCB$W_XM_QUOTA(R5)
08D6 1567 BGTRU 20$
08D8 1568 CLRL R1
08DA 1569 ADDW3 #RCV T DATA+CXB$C TRAILER,-
08DE 1570 UCB$W_DEVBUFSIZ(R5),R1
08E1 1571 TSTL R2
08E3 1572 BNEQ 7$
08E5 1573 JSB G^EXESALONONPAGED
08EB 1574 BLBC R0,10$
08EE 1575 7$: MOVW R1,RCV W_BLKSIZE(R2)
08F2 1576 MOVW S^#DYN$C-NET,RCV B_BLKTYPE(R2)
08F6 1577 INSQUE (R2),UCB$Q_XM_RCV_BUF(R5)
08FB 1578 SUBW UCB$W_DEVBUFSIZ(R5),-
08FE 1579 UCB$W_XM_QUOTA(R5)
0901 1580 CLRL R2
0903 1581 BRB 5$
0905 1582
0905 1583 10$: SETBIT #XMSV_STS_BUFFAIL,-
0905 1584 UCB$L_DEVDEPEND(R5)
090A 1585 BRB 30$
090C 1586
090C 1587 20$: CLRBIT #XMSV_STS_BUFFAIL,-
090C 1588 UCB$L_DEVDEPEND(R5)
0911 1589 MOVL R2,R0
0914 1590 BEQL 30$
0916 1591 JSB G^COM$DRVDEALMEM
091C 1592
```

01 44 A5 D4 08C6 1559 CLRL R2
08C6 1560 BBS #XMSV_STS_ACTIVE,-
08CA 1561 UCB\$L_DEVDEPEND(R5),ADDRCLVLIST
05 08CD 1562 RSB
08CE 1563 ADDRCLVLIST:
08CE 1564 PUSHR #M<R0,R3>
42 A5 B1 08D0 1565 5\$: CMPW UCB\$W_DEVBUFSIZ(R5),-
010C C5 08D3 1566 UCB\$W_XM_QUOTA(R5)
34 1A 08D6 1567 BGTRU 20\$
51 D4 08D8 1568 CLRL R1
004C 8F A1 08DA 1569 ADDW3 #RCV T DATA+CXB\$C TRAILER,-
51 42 A5 08DE 1570 UCB\$W_DEVBUFSIZ(R5),R1
52 D5 08E1 1571 TSTL R2
09 12 08E3 1572 BNEQ 7\$
00000000 GF 16 08E5 1573 JSB G^EXESALONONPAGED
17 50 E9 08EB 1574 BLBC R0,10\$
08 A2 51 B0 08EE 1575 7\$: MOVW R1,RCV W_BLKSIZE(R2)
0A A2 17 90 08F2 1576 MOVW S^#DYN\$C-NET,RCV B_BLKTYPE(R2)
00C0 C5 62 0E 08F6 1577 INSQUE (R2),UCB\$Q_XM_RCV_BUF(R5)
42 A5 A2 08FB 1578 SUBW UCB\$W_DEVBUFSIZ(R5),-
010C C5 08FE 1579 UCB\$W_XM_QUOTA(R5)
52 D4 0901 1580 CLRL R2
CB 11 0903 1581 BRB 5\$
0905 1582
0905 1583 10\$: SETBIT #XMSV_STS_BUFFAIL,-
0905 1584 UCB\$L_DEVDEPEND(R5)
10 11 090A 1585 BRB 30\$
090C 1586
090C 1587 20\$: CLRBIT #XMSV_STS_BUFFAIL,-
090C 1588 UCB\$L_DEVDEPEND(R5)
50 52 D0 0911 1589 MOVL R2,R0
06 13 0914 1590 BEQL 30\$
00000000 GF 16 0916 1591 JSB G^COM\$DRVDEALMEM
091C 1592

: Fill receive buffer list
: Clear buffer address
: Continue if device active
:
: Add to receive buffer list
: Save registers
: Can new block be allocated ?
:
: Br if no - list filled
: Zero size
: Compute needed block size
:
: Buffer allocated already?
: Br if yes
: Allocate nonpaged memory
: Br if failure
: Insert block size
: Insert block type
: Insert block on list
: Decrement quota
:
: Clear buffer pointer
:
: Set buffer alloc failure
:
:
: Clear buffer alloc failure
:
: Set address of buffer
: Br if none
: Deallocate it

XMDRIVER
V04-000

B 4
- VAX/VMS DMC11/DMR11 Device Driver
FILLRCVLIST - Fill receive buffer list

16-SEP-1984 00:26:05
5-SEP-1984 00:20:43

VAX/VMS Macro V04-00
[DRIVER.SRC]XMDRIVER.MAR;1

Page 34
(14)

06	10	091C	1593	30\$:	DSBINT	UCBSB_DIPL(R5)	; Synch access to device
		0923	1594		BSBB	START_RECEIVE	; Start the receives
		0925	1595		ENBINT		; Restore IPL
09	BA	0928	1596		POPR	#^M<R0,R3>	; Restore registers
	05	092A	1597	40\$:	RSB		
		092B	1598				


```
092B 1600 .SBTTL START_RECEIVE - Start any receives
092B 1601 :++
092B 1602 : START_RECEIVE - Start receives
092B 1603 :
092B 1604 : Functional description:
092B 1605 :
092B 1606 : This routine attempts to start any receives that may be pending. This
092B 1607 : involves dequeuing a free receive buffer, mapping, and loading its address
092B 1608 : and size into the device.
092B 1609 :
092B 1610 : Inputs:
092B 1611 :
092B 1612 :     R5 = UCB address
092B 1613 :
092B 1614 :     IPL = DIPL
092B 1615 :
092B 1616 : Outputs:
092B 1617 :
092B 1618 :     R5 preserved.
092B 1619 :
092B 1620 :     R0 - R4 destroyed
092B 1621 :--
092B 1622 START_RECEIVE:
092B 1623     MOVZBL UCB$B_XM_RCV_MAX(R5),R1      ; Start receive operation
0930 1624     FFC      #0,R1,UCB$B_XM_RCV_MAP(R5),R1  ; Get max concurrent receives
0937 1625     BEQL     10$                          ; Get free mapping slot
0939 1626     REMQUE   @UCB$Q_XM_RCV_BUF(R5),R3      ; Br if none
093E 1627     BVC      20$                          ; Get a free buffer
0940 1628 10$:   RSB                                ; Br if buffer
0941 1629 :
0941 1630 : Mark slot in use and create buffer address / character count image,
0941 1631 : and load UNIBUS adapter map registers.
0941 1632 :
0941 1633 20$:   SETBIT   R1,UCB$B_XM_RCV_MAP(R5)      ; Mark slot in use
0947 1634     MOVB      R1,RCV_B_MAPSLOT(R3)           ; Save mapping slot number used
094B 1635     MOVAL     UCB$L_XM_RCV_MAP(R5)[R1],R4    ; Get mapping info slot address
0951 1636     MOVAB     RCV_T_DATA(R3),R1              ; Get receive buffer data addr
0955 1637     MOVW      R1,RCV_L_BACC(R3)                ; Set BA0-BA8
0959 1638     MOVW      UCB$W_DEVBUFSIZ(R5),-          ; Insert character count
095C 1639     RCV_L_BACC+2(R3)                          ;
095E 1640     INSV      (R4),#9,#7,RCV_L_BACC(R3)      ; Set BA9-BA15 from map reg
0964 1641     EXTZV     #7,#2,(R4),R0                  ; Get BA16-BA17 also
0969 1642     INSV      R0,#30,#2,RCV_L_BACC(R3)       ; Set BA16-BA17
096F 1643 :
096F 1644     PUSHL     R3                                ; Save buffer address
0971 1645     MOVZWL     2(R4),R2                          ; Set number of map registers
0975 1646     MOVZWL     (R4),R3                            ; Set first map register number
0978 1647     CLRL      R4                                ; Use unbuffered datapath
097A 1648     JSB       G^IOC$LOADUBAMAPN                ; Load the map registers
0980 1649     POPL      R3                                ; Restore buffer address
0983 1650     BSBB      LOAD_PORT                          ; Load buffer into port
0985 1651     BRB       START_RECEIVE                     ; That was fun - try another
0987 1652
```

51 0108 C5 51 00 EB 0930 1624 FFC #0,R1,UCB\$B_XM_RCV_MAP(R5),R1 ; Get max concurrent receives
53 00C0 D5 07 13 0937 1625 BEQL 10\$; Br if none
01 1C 0939 1626 REMQUE @UCB\$Q_XM_RCV_BUF(R5),R3 ; Get a free buffer
05 093E 1627 BVC 20\$; Br if buffer
0940 1628 10\$: RSB ;
0941 1629 :
0941 1630 : Mark slot in use and create buffer address / character count image,
0941 1631 : and load UNIBUS adapter map registers.
0941 1632 :
0941 1633 20\$: SETBIT R1,UCB\$B_XM_RCV_MAP(R5) ; Mark slot in use
0947 1634 MOV B R1,RCV_B_MAPSLOT(R3) ; Save mapping slot number used
54 0B A3 51 90 094B 1635 MOVAL UCB\$L_XM_RCV_MAP(R5)[R1],R4 ; Get mapping info slot address
51 48 A3 9E 0951 1636 MOVAB RCV_T_DATA(R3),R1 ; Get receive buffer data addr
OC A3 51 B0 0955 1637 MOVW R1,RCV_L_BACC(R3) ; Set BA0-BA8
42 A5 B0 0959 1638 MOVW UCB\$W_DEVBUFSIZ(R5),- ; Insert character count
OE A3 095C 1639 RCV_L_BACC+2(R3) ;
OC A3 07 09 64 F0 095E 1640 INSV (R4),#9,#7,RCV_L_BACC(R3) ; Set BA9-BA15 from map reg
50 64 02 07 EF 0964 1641 EXTZV #7,#2,(R4),R0 ; Get BA16-BA17 also
OC A3 02 1E 50 F0 0969 1642 INSV R0,#30,#2,RCV_L_BACC(R3) ; Set BA16-BA17
096F 1643 :
52 02 A4 3C 0971 1645 MOVZWL 2(R4),R2 ; Save buffer address
53 64 3C 0975 1646 MOVZWL (R4),R3 ; Set number of map registers
54 D4 0978 1647 CLRL R4 ; Set first map register number
00000000 GF 16 097A 1648 JSB G^IOC\$LOADUBAMAPN ; Use unbuffered datapath
53 BED0 0980 1649 POPL R3 ; Load the map registers
02 10 0983 1650 BSBB LOAD_PORT ; Restore buffer address
A4 11 0985 1651 BRB START_RECEIVE ; Load buffer into port
0987 1652 ; That was fun - try another


```
0987 1654 .SBTTL LOAD_PORT - Load controller input port
0987 1655 :++
0987 1656 : LOAD_PORT - Load controller input port
0987 1657 :
0987 1658 : Functional description:
0987 1659 :
0987 1660 : Request the controller's input port to start an I/O request. Since the controller
0987 1661 : doesn't service input requests when it is busy, it may not be attainable
0987 1662 : in a reasonable amount of time. In this case, the driver will just have to
0987 1663 : request an interrupt.
0987 1664 :
0987 1665 : Inputs:
0987 1666 :
0987 1667 : R3 = Transmit I/O packet or receive buffer
0987 1668 : R5 = UCB address
0987 1669 :
0987 1670 : IPL = DIPL
0987 1671 :
0987 1672 : Outputs:
0987 1673 :
0987 1674 : R0 = Success if port loaded immediately
0987 1675 : R4 = CSR address
0987 1676 : R5 = UCB address
0987 1677 :
0987 1678 : R0-R1 destroyed.
0987 1679 :--
0987 1680 LOAD_PORT: ; Load buffer address/size into port
0987 1681 :
0987 1682 : Receive buffers go to head of queue to get initiated first.
0987 1683 : This prevents the link from shutting down due to receive buffer
0987 1684 : starvation.
0987 1685 :
0987 1686 : Note that receive buffers can go onto queue in any order since, they are
0987 1687 : merely empty buckets and one is exactly the same as another. However,
0987 1688 : transmit buffers contain information and their order must be preserved.
0987 1689 :
50 00A4 D5 9E 0987 1690 MOVAB @UCBSQ_XM_PORT+4(R5),R0 ; Assume request goes at tail of queue
OA OA A3 91 098C 1691 CMPB IRPSB_TYPE(R3),S^#DYN$C_IRP ; Is buffer a transmit?
05 13 0990 1692 BEQL 10$ ; Br if yes
50 00A0 C5 9E 0992 1693 MOVAB UCBSQ_XM_PORT(R5),R0 ; Else, get address of head of queue
60 63 0E 0997 1694 10$: INSQUE (R3),R0 ; Insert request in queue
099A 1695
099A 1696 LOAD_PORT_ALT: ; Entry from PORT_INTR routine, order
099A 1697 ; of entries on port queue is preserved
54 24 A5 D0 099A 1698 MOVL UCBSL_CRB(R5),R4 ; Get CRB address
54 2C B4 D0 099E 1699 MOVL @CRBSL_INTD+VEC$SL_IDB(R4),R4 ; Get CSR address
64 20 B3 09A2 1700 BITW #XM_I_M_RQI,(R4) ; Is a request already pending?
65 12 09A5 1701 BNEQ 10$ ; Br if yes - leave
09A7 1702 TIMEWAIT #5,#XM_I_M_RDI,(R4),W,EQL ; Wait for controller to release port
3D 50 E9 09CC 1703 BLBC R0,10$ ; Br if failure - wait for an interrupt
64 20 90 09CF 1704 MOVB #XM_I_M_RQI,(R4) ; Request input port
02 A4 0080 8F B3 09D2 1705 BITW #XM_O_M_RDO,XM_O_CSR(R4) ; Is control out pending?
28 12 09D8 1706 BNEQ 5$ ; Br if yes - request interrupt
09DA 1707 TIMEWAIT #5,#XM_I_M_RDI,(R4),W ; Wait for controller to come ready
OD 50 E8 09FF 1708 BLBS R0,20$ ; Br if success - port now available
0A02 1709
0A02 1710 ; Port is not currently available - request an interrupt and wait
```



```

                                0A02 1711 ; until the interrupt occurs.
                                0A02 1712 ;
64 0060 8F A8 0A02 1713 5$: BISW #XM_I_M_RQI!XM_I_M_IEI,(R4) ; Request interrupt
64 0060 8F A8 0A07 1714 BISW #XM_I_M_RQI!XM_I_M_IEI,(R4) ; (again)
                                D4 0A0C 1715 10$: CLRL R0 ; Set failure to load
                                05 0A0E 1716 RSB ;
                                0A0F 1717 ;
                                0A0F 1718 ; Port is available - load the buffer address and size into the port
                                0A0F 1719 ;
53 00A0 D5 0F 0A0F 1720 20$: REMQUE @UCBSQ_XM_PORT(R5),R3 ; Get first entry on port queue
                                1D 0A14 1721 BVS INPUT_DONE ; Br if none, assume interrupt processed
                                0A16 1722 ; the request.
                                0A16 1723 ;
                                0A16 1724 LOAD_PORT_AVAIL: ; Load port - it's available
                                0A16 1725 CMPB IRPSB_TYPE(R3),S^#DYN$C_IRP ; Is buffer a transmit?
                                0A1A 1726 BEQL 10$ ; Br if yes
                                0A1C 1727 CMPB IRPSB_TYPE(R3),S^#DYN$C_NET ; Is buffer a receive buffer?
                                0A20 1728 BEQL 20$ ; Br if yes
                                0A22 1729 BUG_CHECK NOBUFPCKT,FATAL ; Else, fatal error
                                0A26 1730 ;
                                0A26 1731 ; Load transmit
                                0A26 1732 ;
                                0A26 1733 10$: INSQUE (R3),@UCBSQ_XM_XMT_PND+4(R5) ; Store on pending queue
04 A4 38 A3 B0 0A2B 1734 MOVW IRPSL_MEDIA(R3),XM_PORT(R4) ; Load buffer address and
06 A4 3A A3 B0 0A30 1735 MOVW IRPSL_MEDIA+2(R3),XM_PORT+2(R4) ; character count
00000000'GF 000000FF 8F C1 0A35 1736 ADDL3 #255,G^EXESGL_ABS$TIM,- ; Set 255 second timer
                                6C A5 0A40 1737 UCBSL_DUETIM(R5)
                                03 A8 0A42 1738 BISW #UCBSM_TIM!UCBSM_INT,- ; Enable timer
                                64 A5 0A44 1739 UCBSW_STS(R5)
                                12 11 0A46 1740 BRB 30$ ;
                                0A48 1741 ;
                                0A48 1742 ; Load receive
                                0A48 1743 ;
                                0A48 1744 20$: INSQUE (R3),@UCBSQ_XM_RCV_PND+4(R5) ; Store on pending queue
04 A4 0C A3 B0 0A4D 1745 MOVW RCV_L_BACC(R3),XM_PORT(R4) ; Load buffer address and
06 A4 0E A3 B0 0A52 1746 MOVW RCV_L_BACC+2(R3),XM_PORT+2(R4) ; character count
                                64 04 A8 0A57 1747 BISW #XM_I_M_RCV,(R4) ; Set receive buffer type
                                0A5A 1748 ;
                                0A5A 1749 30$: DSBINT ; Disable all interrupts
05 64 A5 05 E0 0A60 1750 BBS #UCBSV_POWER,UCBSW_STS(R5),40$ ; Br if powerfailed - forget it
64 0060 8F AA 0A65 1751 BICW #XM_I_M_RQI!XM_I_M_IEI,(R4) ; Release port, start transfer
                                0A6A 1752 40$: ENBINT ; Re-enable interrupts
                                0A6D 1753 ;
                                0A6D 1754 INPUT_DONE:
                                50 01 3C 0A6D 1755 MOVZWL S^#SS$_NORMAL,R0 ; Set success loading
                                05 0A70 1756 RSB
                                0A71 1757
```



```
0A71 1759 .SBTTL PORT_INTR - Input port ready interrupt service routine
0A71 1760 :++
0A71 1761 : PORT_INTR - Input port ready interrupt service routine
0A71 1762 :
0A71 1763 : Functional description:
0A71 1764 :
0A71 1765 : This interrupt occurs when the port is ready for the driver to pass a
0A71 1766 : buffer address and buffer size to the controller. Prior to this, a request
0A71 1767 : for the port was made to LOAD_PORT, but the port wasn't available in a
0A71 1768 : short enough amount of time.
0A71 1769 :
0A71 1770 :
0A71 1771 : Inputs:
0A71 1772 :
0A71 1773 : 0(SP) = Address of the unit IDB address
0A71 1774 : 4(SP) - 20(SP) = R1 - R4
0A71 1775 :
0A71 1776 : Outputs:
0A71 1777 :
0A71 1778 : A receive or transmit is loaded, a check is made for any other
0A71 1779 : buffers waiting to be loaded and if there are, another request for
0A71 1780 : the port is made. Finally, the interrupt is dismissed.
0A71 1781 :
0A71 1782 : If the interrupt was unexpected, that is no receives or transmits were
0A71 1783 : pending, the controller is assumed to be in error and is shutdown.
0A71 1784 :--
0A71 1785 PORT_INTR:
0A71 1786 MOVL @ (SP)+,R4 ; Input port ready interrupt
0A74 1787 MOVL IDB$$_UCBLST(R4),R5 ; Get IDB address
0A78 1788 BBC #XM$V_STS_ACTIVE,- ; Get UCB address
0A7A 1789 UCB$$_DEVDEPEND(R5),INTEXIT ; Exit if controller not active
0A7D 1790 MOVL (R4),R4 ; Get CSR address
0A80 1791 BICW3 (R4),#XM_I_M_RDI!XM_I_M_RQI,R0 ; Is a request really pending?
0A86 1792 BNEQ INTEXIT ; Br if not - exit
0A88 1793
0A88 1794 REMQUE @UCB$$_XM_PORT(R5),R3 ; Get a waiting buffer/IRP
0A8D 1795 BVS INTERR ; If VS then none - error
0A8F 1796 BSBW LOAD_PORT_AVAIL ; Load and free the port
0A92 1797
0A92 1798 10$: MOVAB UCB$$_XM_PORT(R5),R0 ; Get address of port queue
0A97 1799 CMPL R0,(R0) ; Any more on queue?
0A9A 1800 BEQL INTEXIT ; Br if no - exit interrupt
0A9C 1801 BSBW LOAD_PORT_ALT ; Attempt to load the port
0A9F 1802 BLBS R0,10$ ; Try another
0AA2 1803 :
0AA2 1804 : Exit interrupt
0AA2 1805 :
0AA2 1806 INTEXIT: ; Exit interrupt
0AA2 1807 MOVQ (SP)+,R0 ; Restore registers
0AA5 1808 MOVQ (SP)+,R2
0AAB 1809 MOVQ (SP)+,R4
0AAB 1810 REI
0AAC 1811 :
0AAC 1812 : An unexpected interrupt occurred. Since there is no NOP function to initiate,
0AAC 1813 : the controller must be shutdown.
0AAC 1814 :
0AAC 1815 INTERR: ;
```

54 9E DO 0A71 1786
55 18 A4 DO 0A74 1787
OB E1 0A78 1788
25 44 A5 0A7A 1789
54 64 DO 0A7D 1790
50 00A0 8F 64 AB 0A80 1791
1A 12 0A86 1792
0A88 1793
53 00A0 D5 0F 0A88 1794
1D 1D 0A8D 1795
FF84 30 0A8F 1796
0A92 1797
50 00A0 C5 9E 0A92 1798
60 50 D1 0A97 1799
06 13 0A9A 1800
FEFB 30 0A9C 1801
F0 50 E8 0A9F 1802
0AA2 1803
0AA2 1804
0AA2 1805
0AA2 1806
50 8E 7D 0AA2 1807
52 8E 7D 0AA5 1808
54 8E 7D 0AAB 1809
02 0AAB 1810
0AAC 1811
0AAC 1812
0AAC 1813
0AAC 1814
0AAC 1815

XMDRIVER
V04-000

- VAX/VMS DMC11/DMR11 Device Driver ^{G 4} 16-SEP-1984 00:26:05 VAX/VMS Macro V04-00 Page 39
PORT_INTR - Input port ready interrupt s 5-SEP-1984 00:20:43 [DRIVER.SRC]XMDRIVER.MAR;1 (17)

024F	30	0AAC	1816	BSBW	TIMEOUT	
F1	11	0AAF	1817	BRB	INEXIT	; Fake a timeout error
		0AB1	1818			;


```

OAB1 1820 .SBTTL CONTROL_INTR - Control out interrupt service routine
OAB1 1821 :++
OAB1 1822 : CONTROL_INTR - Control out interrupt service routine
OAB1 1823 :
OAB1 1824 : FUNCTIONAL DESCRIPTION:
OAB1 1825 :
OAB1 1826 : This routine is the control out interrupt service routine. These interrupts
OAB1 1827 : signal receive or transmit buffer done or errors.
OAB1 1828 :
OAB1 1829 : INPUTS:
OAB1 1830 :
OAB1 1831 : 0(SP) = IDB address
OAB1 1832 : 4(SP) - 20(SP) = R1-R5
OAB1 1833 :
OAB1 1834 : OUTPUTS:
OAB1 1835 :
OAB1 1836 : IMPLICIT OUTPUTS:
OAB1 1837 :
OAB1 1838 : If the interrupt signals an error,
OAB1 1839 : the port is held and the fork process is scheduled to process
OAB1 1840 : the error.
OAB1 1841 :
OAB1 1842 : If the interrupt signals receive done,
OAB1 1843 : the port is freed;
OAB1 1844 : the fork process is scheduled to complete any pending I/O;
OAB1 1845 : the next receive is started if possible.
OAB1 1846 :
OAB1 1847 : If the interrupt signals transmit done,
OAB1 1848 : the port is freed;
OAB1 1849 : the fork process is scheduled to complete the transmit I/O.
OAB1 1850 :--
OAB1 1851 : CONTROL_INTR:
OAB1 1852 : MOVL @ (SP)+,R4 ; Control out interrupt
OAB1 1853 : MOVL IDB$UCBLST(R4),R5 ; Get IDB address
OAB1 1854 : MOVL (R4),R2 ; Get UCB address
OAB1 1855 : BBC #XMSV_STS_ACTIVE,- ; Get CSR address
OAB1 1856 : UCB$DEVDEPEND(R5),INEXIT ; Br if not active
OAB1 1857 : MOVW XM_O_CSR(R2),R4 ; Get output CSR,
OAB1 1858 : ASHL #16,R4,R4 ; shift, and
OAB1 1859 : MOVW XM_I_CSR(R2),R4 ; get input CSR
OAB1 1860 : MOVW XM_PORT+2(R2),R3 ; Get port high word,
OAB1 1861 : ASHL #16,R3,R3 ; shift, and
OAB1 1862 : MOVW XM_PORT(R2),R3 ; get port low word
OAB1 1863 : BBC #XM_O_V_TYPE+16,R4,10$ ; Br if not error
OAB1 1864 : BSBB SCHED_FORK ; Schedule fork process to report error
OAB1 1865 : BRB INEXIT
OAB1 1866 :
OAB1 1867 : 10$: BICW #XM_O_M_RDO,XM_O_CSR(R2) ; Release output port
OAB1 1868 : BICL #^XC0000000,R3 ; Clear BA16 and BA17 from BA/CC
OAB1 1869 : ; (not always correct anyway)
OAB1 1870 : BBC #XM_O_V_RCV+16,R4,40$ ; Br if transmit complete
OAB1 1871 :
OAB1 1872 : : Receive completed. Get the next receive buffer and schedule the fork
OAB1 1873 : : process.
OAB1 1874 :
OAB1 1875 : REMQUE @UCB$Q_XM_RCV_PND(R5),R2 ; Get oldest pending receive
OAB1 1876 : BVS INTERR ; Error if none

```



```
OC A2 53 B1 0AF7 1877 CMPW R3,RCV_L_BACC(R2) ; Buffer address match?
07 13 0AFB 1878 BEQL 30$ ; Br if yes - ok
00B0 C5 62 0E 0AFD 1879 20$: INSQUE (R2),UCB$Q_XM_RCV_PND(R5) ; Requeue the receive buffer
A8 11 0B02 1880 BRB INTERR ; Shutdown the controller
0B04 1881
50 0B A2 9A 0B04 1882 30$: MOVZBL RCV_B_MAPSLOT(R2),R0 ; Get mapping slot number used
EF 0108 C5 50 E5 0B08 1883 DBCC R0,UCB$B_XM_RCV_MAP(R5),20$ ; Mark the slot free
OC A2 53 D0 0B0E 1884 MOVL R3,RCV_L_BACC(R2) ; Save byte count
1F 11 0B12 1885 BRB 100$ ;
0B14 1886 ;
0B14 1887 ; Transmit completed. Get the next transmit I/O packet and schedule fork
0B14 1888 ; process to complete the I/O request.
0B14 1889 ;
52 00A8 D5 0F 0B14 1890 40$: REMQUE @UCB$Q_XM_XMT_PND(R5),R2 ; Get pending transmit I/O packet
91 1D 0B19 1891 BVS INTERR ; Error if none
04 12 0B1B 1892 BNEQ 45$ ; Br if not last one
03 AA 0B1D 1893 BICW #UCB$M_INT!UCB$M_TIM,- ; Disable timer
64 A5 0B1F 1894 UCB$W_STS(R5)
38 A2 53 B1 0B21 1895 45$: CMPW R3,IRP$L_MEDIA(R2) ; Buffer address match?
08 13 0B25 1896 BEQL 60$ ; Br if yes - ok
00A8 C5 62 0E 0B27 1897 50$: INSQUE (R2),UCB$Q_XM_XMT_PND(R5) ; Requeue the I/O packet
FF7D 31 0B2C 1898 BRW INTERR ; Shutdown the controller
0B2F 1899
38 A2 53 D0 0B2F 1900 60$: MOVL R3,IRP$L_IOST1(R2) ; Save byte count
0B33 1901
00BC D5 62 0E 0B33 1902 100$: INSQUE (R2),@UCB$Q_XM_POST+4(R5) ; Queue receive buffer or I/O packet
03 12 0B38 1903 BNEQ 110$ ; Br if not first entry
001E 30 0B3A 1904 BSBW SCHED_FORK ; Schedule fork process
0B3D 1905 ;
0B3D 1906 ; An input buffer may be waiting to be loaded, but for some reason, the
0B3D 1907 ; port was unable to be requested. Check for this condition and if occurring,
0B3D 1908 ; attempt to load the port. Also, since we may have freed-up a receive slot,
0B3D 1909 ; it may be possible to load another receive.
0B3D 1910 ;
10 54 05 E0 0B3D 1911 110$: BBS #XM_I_V_RQ1,R4,120$ ; Br if input request already pending
50 00A0 C5 9E 0B41 1912 115$: MOVAB UCB$Q_XM_PORT(R5),R0 ; Get address of input request queue
60 50 D1 0B46 1913 CMPL R0,(R0) ; Anything on queue?
06 13 0B49 1914 BEQL 120$ ; Br if no - start receives
FE4C 30 0B4B 1915 BSBW LOAD_PORT_ALT ; Load and free the port
F0 50 E8 0B4E 1916 BLBS R0,1T5$ ; Br if success - try for another
03 54 12 E1 0B51 1917 120$: BBC #XM_O_V_RCV+16,R4,130$ ; Br if last transfer wasn't receive
FDD3 30 0B55 1918 BSBW START_RECEIVE ; Start any receives
FF47 31 0B58 1919 130$: BRW INTEXIT ; Exit
0B5B 1920
```



```
OB5B 1922 .SBTTL SCHED_FORK - Schedule the fork process
OB5B 1923 :++
OB5B 1924 : SCHED_FORK - Schedule the fork process
OB5B 1925 :
OB5B 1926 : Functional description:
OB5B 1927 :
OB5B 1928 : This routine is called to schedule the error and I/O completion fork process.
OB5B 1929 : The last controller port and CSR values are saved for examination.
OB5B 1930 : If the process's execution is already pending, the last port and CSR values
OB5B 1931 : are just saved.
OB5B 1932 :
OB5B 1933 : Inputs:
OB5B 1934 :
OB5B 1935 :     R3 = Last port values
OB5B 1936 :     R4 = Last CSR values
OB5B 1937 :     R5 = UCB address
OB5B 1938 :
OB5B 1939 :     IPL = DIPL or higher
OB5B 1940 :
OB5B 1941 : Outputs:
OB5B 1942 :
OB5B 1943 :     R5 = UCB address
OB5B 1944 :
OB5B 1945 :     UCB$L_XM_LSTPRT(R5) = Last port values
OB5B 1946 :     UCB$L_XM_LSTCSR(R5) = Last CSR values
OB5B 1947 : --
OB5B 1948 SCHED_FORK:
OB5B 1949 BBSS #UCB$V_XM_FORK_PEND,- ; Schedule fork process for execution
18 68 A5 E2 OB5D 1950 UCB$W_DEVSTS(R5),10$ ; Br if fork process scheduling pending
55 DD OB60 1951 PUSHL R5 ; Save R5
04 10 OB62 1952 BSBB S$ ; Setup fork process
55 8ED0 OB64 1953 POPL R5 ; Restore R5
05 OB67 1954 RSB ; Return to caller
OB68 1955
55 00000138 8F C0 OB68 1956 5$: ADDL #UCB$B_XM_FKB,R5 ; Point to fork block
84 AF 9F OB6F 1957 PUSHAB B^FORK_PROG ; Set address of fork process
00000000 GF 17 OB72 1958 JMP G^EXESFORK ; Schedule FORK and return to caller
OB78 1959
05 54 10 E1 OB78 1960 10$: BBC #XM_O_V_TYPE+16,R4,20$ ; Br if not an error to handle
0148 C5 53 7D OB7C 1961 MOVQ R3,UCB$L_XM_LSTPRT(R5) ; Save last port and CSR values
05 OB81 1962 20$: RSB ;
OB82 1963
```



```
OB82 1965 .SBTTL FORK_PROC - Error and I/O completion fork process
OB82 1966 :++
OB82 1967 : FORK_PROC - Error and I/O completion fork process
OB82 1968 :
OB82 1969 : Functional description:
OB82 1970 :
OB82 1971 : This routine is called as a fork process to handle errors and I/O
OB82 1972 : completions.
OB82 1973 :
OB82 1974 : Inputs:
OB82 1975 :
OB82 1976 : R3 = Last port values
OB82 1977 : R4 = Last CSR values
OB82 1978 : R5 = UCB address at FORK BLOCK
OB82 1979 :
OB82 1980 : IPL = FIPL
OB82 1981 :
OB82 1982 : Outputs:
OB82 1983 :
OB82 1984 : R5 preserved.
OB82 1985 : --
017C' OB82 1986 : .WORD TIMEOUT- ; Offset to timeout routine
OB84 1987 FORK_PROC: ; Error/completion fork process
OB84 1988 CLRBIT #UCBSV_XM_FORK_PEND,- ; Clear fork process scheduling pending
OB84 1989 UCB$W_DEVSTS-UCB$B_XM_FKB(R5)
OB8A 1990 SUBL #UCB$B_XM_FKB,R5 ; Point to UCB
OB91 1991 BBC #XM_0_V_TYPE+16,R4,20$ ; Br if not error
OB95 1992 BSBW DEVICE_ERROR ; Handle the error
OB98 1993 :
OB98 1994 : Complete any transmits or receives
OB98 1995 :
52 00B8 D5 0F OB98 1996 20$: REMQUE @UCB$Q_XM_POST(R5),R2 ; Get next completed block
01 1C OB9D 1997 BVC 23$ ; Br if one
05 OB9F 1998 RSB ; Else, return
0A 0A A2 91 OBA0 1999 23$: CMPB IRP$B_TYPE(R2),S^#DYN$C_IRP ; Was it a transmit I/O?
47 13 OBA4 2000 BEQL 50$ ; Br if yes - complete it
17 0A A2 91 OBA6 2001 CMPB IRP$B_TYPE(R2),S^#DYN$C_NET ; Was it a receive?
04 13 OBAA 2002 BEQL 24$ ; Br if yes
OBAC 2003 BUG_CHECK NOBUFPCKT,FATAL ; Else, fatal error
OB80 2004 :
OB80 2005 : Receive completed - if there is a pending receive I/O request, complete it.
OB80 2006 : Otherwise, queue the buffer and, if enabled, send a message to mailbox.
OB80 2007 :
51 0E A2 3C OB80 2008 24$: MOVZWL RCV L BACC+2(R2),R1 ; Get the byte count
OB84 2009 ADDLC R1,UCB$L_RCVBYTCNT(R5) ; Update byte count
0128 C5 D6 OBC0 2010 INCL UCB$L_RCVMSGCNT(R5) ; Update message count
53 0098 D5 0F OBC4 2011 REMQUE @UCB$Q_XM_RCV_REQ(R5),R3 ; Remove waiting receive I/O request
04 1D OBC9 2012 BVS 25$ ; Br if none - queue for later
68 10 OBCB 2013 BSBW FINISH_RCV_IO ; Else, finish the I/O
C9 11 OBCE 2014 BRB 20$
OBCE 2015 :
00CC D5 62 0E OBCF 2016 25$: INSQUE (R2),@UCB$Q_XM_RCV_MSG+4(R5); Else, queue message buffer
54 D4 OBD4 2017 CLRL R4 ; Set no mailbox
0B E0 OBD6 2018 BBS #UCBSV_XM_NOTIF,- ; Br if already notified
04 68 A5 OBD8 2019 UCB$W_DEVSTS(R5),30$
54 00'8F 9A OBD8 2020 MOVZBL #MSG$-XM_DATAVL,R4 ; Set message type
00D8 30 OBD8 2021 30$: BSBW POKE_USER ; Poke the user
```



```
06 50 E9 OBE2 2022 BLBC R0,40$ ; If low clear then not sent
0800 8F AB OBE5 2023 BISW #UCBSM_XM_NOTIF - ; Set notified
68 A5 OBE9 2024 UCB$W_DEVSTS(R5) ;
AB 11 OBEB 2025 40$: BRB 20$ ;
OBED 2026 ;
OBED 2027 ;
OBED 2028 ; Transmit completed - deallocate the map registers and complete the I/O
OBED 2029 ; request. If there is a transmit request waiting for mapping resources,
OBED 2030 ; restart it.
OBED 2031 ;
53 52 D0 OBED 2032 50$: MOVL R2,R3 ; Get I/O packet address
51 32 A3 3C OBF0 2033 MOVZWL IRPSW BCNT(R3),R1 ; Get byte count
O12C C5 D6 OC00 2034 ADDLC R1,UCBSL_XMTBYTCNT(R5) ; Update byte count
51 3C A3 9A OC04 2035 INCL UCB$XMTMSGCNT(R5) ; Update message count
52 24 A5 D0 OC08 2036 MOVZBL IRPSL-MEDIA+4(R3),R1 ; Get mapping slot number used
34 A2 00EC C541 D0 OC0E 2037 CLRBIT R1,UCBSB_XM_XMT_MAP(R5) ; Clear in use flag
D0 OC12 2038 MOVL UCB$X_CRB(R5),R2 ; Get CRB address
00EC C541 01 CE OC19 2039 MOVL UCB$X_XM_XMT_MAP(R5)[R1],- ; Setup map register data
OC1F 2040 CRBSL-INTD+VECSW MAPREG(R2)
50 32 A3 B0 OC25 2041 MNEGL #1,UCBSL_XM_XMT_MAP(R5)[R1] ; Set mapping data not allocated
50 50 10 78 OC29 2042 RELMPR ; Release the map registers
50 01 B0 OC2D 2043 MOVW IRPSW BCNT(R3),R0 ; Get count of bytes transmitted
3E 10 OC30 2044 ASHL #16,R0,R0 ; Shift into place
OC32 2045 MOVW S^#SS$ NORMAL,R0 ; Set success
F4DE 30 OC32 2046 BSBB IO_DONE ; Post the I/O
FF60 31 OC35 2047 BSBW XMT_START_ALT ; Continue any waiting requests
OC38 2048 BRW 20$ ;
OC38 2050
```



```
OC38 2052 .SBTTL FINISH_RCV_IO - Finish receive I/O processing
OC38 2053 :++
OC38 2054 : FINISH_RCV_IO - Finish receive I/O processing
OC38 2055 :
OC38 2056 : FUNCTIONAL DESCRIPTION:
OC38 2057 :
OC38 2058 : This routine completes a receive operation that has been matched with a
OC38 2059 : message block. After the receive has been completed the message free list is
OC38 2060 : filled and a receive is started if needed.
OC38 2061 :
OC38 2062 : INPUTS:
OC38 2063 :
OC38 2064 : R2 = message buffer address
OC38 2065 : R3 = I/O packet address
OC38 2066 : R5 = UCB address
OC38 2067 :
OC38 2068 : IPL = FIPL
OC38 2069 :
OC38 2070 : OUTPUTS:
OC38 2071 :
OC38 2072 : R5 = UCB address
OC38 2073 :
OC38 2074 : The request is completed via I/O post.
OC38 2075 :--
OC38 2076 : FINISH_RCV_IO:
OC38 2077 : MOVL R2,IRPSL_SVAPTE(R3) ; Finish receive I/O request
OC38 2078 : MOVAB RCV_T_DATA(R2),(R2) ; Save block address
OC38 2079 : MOVL IRPSL_MEDIA(R3),4(R2) ; Set address of received data
OC38 2080 : ADDW UCB$W_DEVBUFSIZ(R5),- ; Set address of user buffer
OC38 2081 : UCB$W_XM_QUOTA(R5) ; Adjust receive buffer quota
OC38 2082 : MOVW RCV_L_BAC(C+2(R2),R1) ; Get size of transfer
OC38 2083 : CMPW R1,IRPSW_BCNT(R3) ; Request larger than actual?
OC38 2084 : BLEQU 20$ ; Br if no
OC38 2085 : MOVZWL IRPSW_BCNT(R3),R1 ; Set size to minimum of two sizes
OC38 2086 : MOVW R1,IRPSW_BCNT(R3) ; Set size to transfer
OC38 2087 : ASHL #16,R1,R0 ; Set up status
OC38 2088 : BNEQ 25$ ; Br if success
OC38 2089 : MOVW #SS$_CTRLERR,R0 ; Set data path error
OC38 2090 : BRB 30$
OC38 2091 : MOVW S^#SS$_NORMAL,R0 ; Set success
OC38 2092 : BSBW 30$ ; Load another receive
OC38 2093 :
OC38 2094 : Complete a transfer I/O request
OC38 2095 :
OC38 2096 : IO_DONE:
OC38 2097 : MOVL R0,IRPSL_IOST1(R3) ; Complete a transfer I/O request
OC38 2098 : MOVL UCB$W_DEVDEPEND(R5),IRPSL_IOST2(R3) ; Set status and size
OC38 2099 : BBC #IRPSW_DIAGBUF,IRPSW_STS(R3),10$ ; Set other info
OC38 2100 : ADDL3 #8,@IRPSL_DIAGBUF(R3),R0 ; Br if no diagnostic buffer
OC38 2101 : MOVQ G^EXESGQ_SYSTIME,(R0)+ ; Address buffer past start time
OC38 2102 : MOVZWL UCB$W_ERRCNT(R5),(R0)+ ; Insert stop time
OC38 2103 : BSBB REGDUMP ; Insert error counter
OC38 2104 : JMP G^COM$POST ; Dump registers
OC38 2105 : ; Post the I/O and return
```

2C A3 52 DO OC38 2077
62 48 A2 9E OC3C 2078
04 A2 38 A3 DO OC40 2079
42 A5 A0 OC45 2080
010C C5 OC48 2081
51 0E A2 B0 OC4B 2082
32 A3 51 B1 OC4F 2083
04 1B OC53 2084
51 32 A3 3C OC55 2085
32 A3 51 B0 OC59 2086
50 51 10 78 OC5D 2087
07 12 OC61 2088
50 0054 8F B0 OC63 2089
03 11 OC68 2090
50 01 B0 OC6A 2091
FC56 30 OC6D 2092
OC70 2093
OC70 2094
OC70 2095
OC70 2096
38 A3 50 DO OC70 2097
3C A3 44 A5 DO OC74 2098
13 2A A3 07 E1 OC79 2099
50 4C B3 08 C1 OC7E 2100
80 00000000'GF 7D OC83 2101
80 0082 C5 3C OC8A 2102
06 10 OC8F 2103
00000000'GF 17 OC91 2104
OC97 2105


```

0C97 2107 .SBTTL REGDUMP - Error log and diagnostics register dump
0C97 2108 :++
0C97 2109 : REGDUMP - Error log and diagnostics register dump routine
0C97 2110 :
0C97 2111 : Functional description:
0C97 2112 :
0C97 2113 : This routine is used to return the controller error counters if a diagnostic
0C97 2114 : buffer was specified for an I/O request.
0C97 2115 :
0C97 2116 : Inputs:
0C97 2117 :
0C97 2118 : R0 = Diagnostic buffer address
0C97 2119 : R5 = UCB address
0C97 2120 :
0C97 2121 : Outputs:
0C97 2122 :
0C97 2123 : R5 = UCB address
0C97 2124 :
0C97 2125 : R0-R1 destroyed.
0C97 2126 :--
0C97 2127 REGDUMP:
80 80 08 9A 0C97 2128 MOVZBL #8,(R0)+ ; Dump registers and counters
80 014C C5 D0 0C9A 2129 MOVL UCB$$_XM_LSTCSR(R5),(R0)+ ; Insert number longwords returned
80 0148 C5 D0 0C9F 2130 MOVL UCB$$_XM_LSTPRT(R5),(R0)+ ; Insert last CSR value
80 80 7C 0CA4 2131 CLRQ (R0)+ ; Insert last port value
0A 44 A5 E1 0CA6 2132 BBC #XMSV_STS_ACTIVE,- ; Zero error counters
51 0118 C5 D0 0CA8 2133 UCB$$_DEVDEPEND(R5),10$ ; Br if not active
F8 A0 03 A1 7D 0CAB 2134 MOVL UCB$$_XM_BASCTAB(R5),R1 ; Get address of base table
80 7C 0CB0 2135 ASSUME UCB$$_XM_DEVCNT EQ 8
80 60 7C 0CB5 2136 MOVQ 3(R1),-8(R0) ; Return error counters
05 0CB7 2137 CLRQ (R0)+ ; Clear other counters
0CBA 2138 CLRQ (R0)
0CBA 2139 RSB
0CBA 2140

```



```
OCBA 2142 .SBTTL POKE_USER - Poke user process on attention condition
OCBA 2143 :++
OCBA 2144 : POKE_USER - Poke user process on attention condition
OCBA 2145 :
OCBA 2146 : Functional description:
OCBA 2147 :
OCBA 2148 : This routine is used when data is available or a controller error occurs.
OCBA 2149 : the action is to deliver any attention AST's and send a message to the
OCBA 2150 : associated mailbox.
OCBA 2151 :
OCBA 2152 : Inputs:
OCBA 2153 :
OCBA 2154 :     R4 = Mailbox message type
OCBA 2155 :     = Zero if none
OCBA 2156 :     R5 = UCB address
OCBA 2157 :
OCBA 2158 : Outputs:
OCBA 2159 :
OCBA 2160 :     R0 = Low bit clear only if user is not notified
OCBA 2161 :     R5 = UCB address
OCBA 2162 :--
OCBA 2163 POKE_USER:
OCBA 2164 CLRL -(SP) ; Poke user process
OCBA 2165 PUSHL R4 ; Assume failure
OCBA 2166 MOVAB UCB$$_XM_AST(R5),R1 ; Save message type
OCBA 2167 TSTL (R1) ; Get AST listhead
OCBA 2168 BEQL 17$ ; Empty ?
OCBA 2169 INCL 4(SP) ; If so, branch
OCBA 2170 MOVL R1,R4 ; Indicate success
OCBA 2171 MOVL (R1),R1 ; Copy listhead address
OCBA 2172 BEQL 15$ ; Get address of next block
OCBA 2173 MOVL UCB$$_DEVDEPEND(R5),- ; Br if none - done
OCBA 2174 ACB$$_KAST+4(R1) ; Save status as new AST parameter
OCBA 2175 BRB 10$ ;
OCBA 2176 JSB G^COM$DELATTNAST ; Deliver the AST's
OCBA 2177 OCDF 2177
OCBA 2178 POPL R4 ; Get mailbox message type
OCBA 2179 BEQL 30$ ; Br if none - no mailbox message
OCBA 2180 MOVL UCB$$_AMB(R5),R3 ; Get mailbox message address
OCBA 2181 BEQL 30$ ; Br if none
OCBA 2182 BBC #XMSV_CHR_MBX,UCB$$_DEVDEPEND(R5),30$ ; Br if disabled
OCBA 2183 JSB G^EXE$$NDEVMSG ; Send the mailbox message
OCBA 2184 BLBC (SP)+,35$ ; If AST failed, keep R0
OCBA 2185 PUSHL #1 ; Else force success
OCBA 2186 POPL R0 ; Set status
OCBA 2187 RSB ;
OCBA 2188 OCFE 2188
```

51 0114 C5 9E OCBE 2166 MOVAB UCB\$\$_XM_AST(R5),R1 ; Get AST listhead
61 D5 OCC3 2167 TSTL (R1) ; Empty ?
18 13 OCC5 2168 BEQL 17\$; If so, branch
04 AE D6 OCC7 2169 INCL 4(SP) ; Indicate success
54 51 D0 OCCA 2170 MOVL R1,R4 ; Copy listhead address
51 61 D0 OCCD 2171 MOVL (R1),R1 ; Get address of next block
07 13 OCD0 2172 BEQL 15\$; Br if none - done
44 A5 D0 OCD2 2173 MOVL UCB\$\$_DEVDEPEND(R5),- ; Save status as new AST parameter
1C A1 OCD5 2174 ACB\$\$_KAST+4(R1) ;
F4 11 OCD7 2175 BRB 10\$;
00000000 GF 16 OCD9 2176 JSB G^COM\$DELATTNAST ; Deliver the AST's
54 BED0 OCDF 2177
16 13 OCE2 2178 POPL R4 ; Get mailbox message type
53 60 A5 D0 OCE4 2179 BEQL 30\$; Br if none - no mailbox message
10 13 OCE8 2180 MOVL UCB\$\$_AMB(R5),R3 ; Get mailbox message address
0B 44 A5 04 E1 OCEA 2181 BEQL 30\$; Br if none
00000000 GF 16 OCEF 2182 BBC #XMSV_CHR_MBX,UCB\$\$_DEVDEPEND(R5),30\$; Br if disabled
05 8E E9 OCF5 2183 JSB G^EXE\$\$NDEVMSG ; Send the mailbox message
01 DD OCF8 2184 BLBC (SP)+,35\$; If AST failed, keep R0
50 BED0 OCFA 2185 PUSHL #1 ; Else force success
05 OCFD 2186 POPL R0 ; Set status
OCFE 2187 RSB ;
OCFE 2188


```
OCFE 2190 .SBTTL TIMEOUT - Transmit timeout handler
OCFE 2191 :++
OCFE 2192 : TIMEOUT - Transmit timeout handler
OCFE 2193 :
OCFE 2194 : Functional description:
OCFE 2195 :
OCFE 2196 : This routine is called by the system clock routine to handle a timed-out
OCFE 2197 : unit. Transmits are the only I/O that is timed for this device. If it
OCFE 2198 : has timed-out, the error handling fork process is scheduled.
OCFE 2199 :
OCFE 2200 : Inputs:
OCFE 2201 :
OCFE 2202 : R5 = UCB address
OCFE 2203 :
OCFE 2204 : Outputs:
OCFE 2205 :
OCFE 2206 : R5 is preserved.
OCFE 2207 :--
OCFE 2208 TIMEOUT:
OCFE 2209 BBC #XMSV_STS_ACTIVE,- ; Timeout handler
OCFE 2210 UCB$[DEV]DEPEND(R5),20$ ; Br if controller inactive
OCFE 2211 ASHL #XM_E_V_TIMEOUT+16,#1,R3 ; Set timeout flag
OCFE 2212 BBC #UCB$V_POWER,UCB$W_STS(R5),10$ ; Br if not powerfail
OCFE 2213 SETBIT #XM_E_V_POWER+16,R3 ; Set powerfail flag too
OCFE 2214 10$: ASHL #XM_O_V_TYPE+16,#1,R4 ; Set error flag
OCFE 2215 BSBW SCHED_FORK ; Schedule the fork process
OCFE 2216 20$: RSB
OCFE 2217
```

0B E1
14 44 A5 78
53 01 1B 05
04 64 A5 05
54 01 10 78
FE44 30
05 OD17
OD18


```
OD18 2219 .SBTTL DEVICE_ERROR - Device error handler
OD18 2220 :++
OD18 2221 : DEVICE_ERROR - Device error handler
OD18 2222 :
OD18 2223 : Functional description:
OD18 2224 :
OD18 2225 : This procedure is called to handle device errors. If the error is non-fatal,
OD18 2226 : the action is simply to, if enabled, send a mailbox message to the device
OD18 2227 : owner. If the error is fatal, the fatal error status is saved away in
OD18 2228 : the UCB, if enabled, a mailbox message is sent to the device owner, and the
OD18 2229 : device is shutdown.
OD18 2230 :
OD18 2231 : Inputs:
OD18 2232 :
OD18 2233 : R3 = Last port values
OD18 2234 : R4 = Last CSR values
OD18 2235 : R5 = UCB address
OD18 2236 :
OD18 2237 : IPL = FIPL
OD18 2238 :
OD18 2239 : Outputs:
OD18 2240 :
OD18 2241 : R5 preserved.
OD18 2242 :--
OD18 2243 : DEVICE_ERROR:
OD18 2244 : MOVL UCB$C_CRB(R5),R0 ; Device error handler
OD18 2245 : MOVL @CRB$C_INTD+VEC$C_IDB(R0),R0 ; Get CRB address
OD18 2246 : BICW #XM_O_M_RDO,XM_O_CSR(R0) ; Get CSR address
OD18 2247 : ASHL #-16,R3,R3 ; Free the port
OD18 2248 : INCW UCB$W_ERRCNT(R5) ; Get last port error value
OD18 2249 : BITW #<XM_E_M_PROCERR!- ; Increment error count
OD18 2250 : XM_E_M_NONEXMEM!- ; Was error a fatal error?
OD18 2251 : XM_E_M_START!-
OD18 2252 : XM_E_M_LOST!-
OD18 2253 : XM_E_M_POWER!-
OD18 2254 : XM_E_M_TIMEOUT!-
OD18 2255 : XM_E_M_MOP>,R3
OD18 2256 : BNEQ 20$ ; Br if yes
OD18 2257 : BISB R3,UCB$C_DEVDEPEND+1(R5) ; Save error status
OD18 2258 : MOVZBL #MSG$_XM_ATTEN,R4 ; Set mailbox message type
OD18 2259 : BRW POKE_USER ; If enabled, send mailbox message
OD18 2260 : ; and return
OD18 2261 :
OD18 2262 : Fatal error - device must be shutdown
OD18 2263 :
OD18 2264 : 20$: BICW #XMSM_STS_ACTIVE,- ; Clear active flag
OD18 2265 : UCB$C_DEVDEPEND(R5)
OD18 2266 : ASSUME <XM_E_M_MOP!XM_E_M_LOST!XM_E_M_START> LE <^XFF>
OD18 2267 : BICB3 #^C<XM_E_M_MOP!- ; Save MOP, lost, and start flags
OD18 2268 : XM_E_M_LOST!-
OD18 2269 : XM_E_M_START>,R3,-
OD18 2270 : UCB$C_DEVDEPEND+2(R5)
OD18 2271 : BBS #XM_E_V_PROCERR,R3,40$ ; Br if procedure error - don't notify
OD18 2272 : ASSUME <XMSM_ERR_FATAL@-16> LE <^XFF>
OD18 2273 : BISB #XMSM_ERR_FATAL@-16,- ; Set fatal error flag
OD18 2274 : UCB$C_DEVDEPEND+2(R5)
OD18 2275 : 30$: MOVZBL #MSG$_XM_SHUTDN,R4 ; Set mailbox message type
```

50 24 A5 D0
50 2C B0 D0
02 A0 0080 8F AA
53 53 F0 8F 78
0082 C5 B6
53 0F98 8F B3

0B 12
45 A5 53 88
54 00'8F 9A
FF79 31

0800 8F AA
44 A5

46 A5 53 67 8F 8B

14 53 09 E0

01 88
46 A5
54 00'8F 9A

XMDRIVER
V04-000

E 5
- VAX/VMS DMC11/DMR11 Device Driver
DEVICE_ERROR - Device error handler

16-SEP-1984 00:26:05 VAX/VMS Macro V04-00
5-SEP-1984 00:20:43 [DRIVER.SRC]XMDRIVER.MAR;1

Page 50
(25)

FF5E	30	0D59	2276	BSBW	POKE_USER	:	If enabled, send mailbox message
06 50	E8	0D5C	2277	BLBS	RO, 40\$:	Br if successful
1000 8F	A8	0D5F	2278	BISW	#UCBSM XM LOSTERR,-	:	Else, remember lost error
68 A5		0D63	2279		UCBSW DEVSTS(R5)	:	
3E	11	0D65	2280	BRB	SHUTDOWN	:	Shutdown device and return
		0D67	2281			:	


```
OD67 2283      .SBTTL SHUTDOWN - Shut down device
OD67 2284      .SBTTL CANCEL - Cancel I/O and Deassign Routine
OD67 2285      :++
OD67 2286      : SHUTDOWN - Shut down device
OD67 2287      : CANCEL - Cancel I/O and Deassign Routine
OD67 2288      :
OD67 2289      : Functional description:
OD67 2290      :
OD67 2291      : This routine is used to shut down the device unit as a result of a
OD67 2292      : SETMODE and SHUTDOWN request, a $CANCEL, or a fatal error. The action is
OD67 2293      : to halt the device, deallocate the basetable, deallocate receive
OD67 2294      : buffers, deallocate all map registers, abort all transmit and receive
OD67 2295      : I/O requests, and restore the quotas to the starting process.
OD67 2296      :
OD67 2297      : Inputs:
OD67 2298      :
OD67 2299      :     R5 = UCB address
OD67 2300      :     RB = Cancel reason code (zero if $CANCEL else $DASSGN)
OD67 2301      :
OD67 2302      :     IPL = FIPL
OD67 2303      :
OD67 2304      : Outputs:
OD67 2305      :
OD67 2306      :     R0-R3 are destroyed.
OD67 2307      :--
OD67 2308      :
OD67 2309      CANCEL:                                : Cancel I/O routine
5C A5 B5 OD67 2310      TSTW   UCB$W_REFC(R5)          : Is this the last $DASSGN or $CANCEL?
31 13 OD6A 2311      BEQL   100$                        : Br if yes
OD6C 2312      :
OD6C 2313      : NOT the last $CANCEL or last $DASSGN
OD6C 2314      :
OD6C 2315      : Perform only a selective $CANCEL (same for $DASSGN)
OD6C 2316      :
2B 68 A5 E1 OD6C 2317      BBC   #UCB$V_XM_INITED,-      : Br if unit NOT inited
OD6E 2318      UCB$W_DEVSTS(R5),10$
OD71 2319      :
OD71 2320      : Flush all attention ASTs for this CHANNEL
OD71 2321      :
57 00D4 8F BB OD71 2322      PUSHR  #^M<R2,R4,R6,R7>      : Save registers
0114 C5 9E OD75 2323      MOVAB  UCB$X_XM_AST(R5),R7      : Get address of AST listhead
56 52 3C OD7A 2324      MOVZWL  R2,R6                      : Get channel number
00000000 GF 16 OD7D 2325      JSB   G^COM$FLUSHATTNS      : Flush all AST for this channel
00D4 8F BA OD83 2326      POPR   #^M<R2,R4,R6,R7>      : Restore registers
OD87 2327      :
OD87 2328      : Complete all associated receive IRPs
OD87 2329      :
56 56 DD OD87 2330      PUSHL  R6                          : Save R6
0098 C5 9E OD89 2331      MOVAB  UCB$Q_XM_RCV_REQ(R5),R6  : Get address of receive IRPs
0153 30 OD8E 2332      BSBW   DO_CANCEL                  : Do the cancel
56 0090 C5 9E OD91 2333      MOVAB  UCB$Q_XM_XMT_REQ(R5),R6 : Get address of XMIT IRPs
014B 30 OD96 2334      BSBW   DO_CANCEL                  : Do the cancel
56 8ED0 OD99 2335      POPL   R6                          : Restore R6
05 OD9C 2336      10$:   RSB                                : Return to caller
OD9D 2337      :
OD9D 2338      :
OD9D 2339      : Last $CANCEL or last $DASSGN request
```



```

51 01 9A 0D9D 2340 : 100$: MOVZBL #1,R1 ; Assume last $DASSGN system service
0D9D 2341 : ; modem is cleared only on last $DASSGN
58 01 91 0DA0 2342 :
02 13 0DA3 2343 : CMPB #CAN$C_DASSGN,R8 ; Is this a $DASSGN?
0DA5 2344 : BEQL SHUTDOWN_ALT ; Br if yes, shutdown the modem
0DA5 2345 :
0DA5 2346 : ; Shutdown request on unit
0DA5 2347 :
0DA5 2348 :
0DA5 2349 : SHUTDOWN: ; Shut down unit
51 D4 0DA5 2350 : CLRL R1 ; Do not shutdown the modem
0DA7 2351 :
0DA7 2352 : SHUTDOWN_ALT:
0B 64 A5 E1 0DA7 2353 : BBC #UCB$V_ONLINE,- ; Br if not online
07 68 A5 E0 0DA9 2354 : UCB$W_STS(R5),10$ ;
03 51 E9 0DAC 2355 : BBS #UCB$V_XM_INITED,- ; Br if UCB initialized
0161 30 0DAE 2356 : UCB$W_DEVSTS(R5),15$ ;
05 05 0DB1 2357 : BLBC R1,10$ ; Br if not to clear DTR
0DB4 2358 : BSBW DISABLE_MODEM ; Else, disable the modem
0DB7 2359 : RSB ; Exit
0DB8 2360 :
0DB8 2361 : ; Clear device and device status
0DB8 2362 :
54 00D0 8F BB 0DB8 2363 : 15$: PUSHR #^M<R4,R6,R7> ; Save registers
24 A5 D0 0DBC 2364 : MOVL UCB$C_CRB(R5),R4 ; Get CRB address
0DC0 2365 : ASSUME IDB$C_CSR EQ 0
54 2C B4 D0 0DC0 2366 : MOVL @CRB$C_INTD+VEC$C_IDB(R4),R4 ; Get CSR address
0DC4 2367 : DSBINT UCB$B_DIPL(R5) ; Synch access to status flags
64 4000 8F B0 0DCB 2368 : MOVW #XM_I_M_MCLR,(R4) ; Master clear the unit
64 A5 23 AA 0DD0 2369 : BICW #UCB$M_INT!UCB$M_TIM!- ; Reset device status flags
0800 8F AA 0DD4 2370 : UCB$M_POWER,UCB$W_STS(R5) ;
44 A5 AA 0DD4 2371 : BICW #XMSM_STS_ACTIVE,- ; Reset active flag
0DD8 2372 : UCB$C_DEVDEPEND(R5) ;
AA 0DDA 2373 : BICW #^C<UCB$M_XM_LOSTERR!- ; Clear all but lost error bit,
0DDB 2374 : UCB$M_XM_FORK_PEND>,- ; and fork process pending
68 A5 CFFF 8F 0DDB 2375 : UCB$W_DEVSTS(R5) ;
03 51 E9 0DE0 2376 : BLBC R1,17$ ; Br if not to clear DTR
0132 30 0DE3 2377 : BSBW DISABLE_MODEM ; Disable the modem
0DE6 2378 : ENBINT ; Restore IPL
0DE9 2379 :
0DE9 2380 : ; Deallocate all the attention AST control blocks
0DE9 2381 :
57 0114 C5 9E 0DE9 2382 : 20$: MOVAB UCB$C_XM_AST(R5),R7 ; Get address of AST listhead
50 67 D0 0DEE 2383 : MOVL (R7),R0 ; Anything in the list?
1B 13 0DF1 2384 : BEQL 25$ ; Br if not
56 22 A0 3C 0DF3 2385 : MOVZWL ACB$C_KAST+10(R0),R6 ; Force channel match
52 24 A0 3C 0DF7 2386 : MOVZWL ACB$C_KAST+12(R0),R2 ; Get process index
54 00000000'GF D0 0DFB 2387 : MOVL G^SCH$GL_PCBVEC,R4 ; Get PCB address vector address
54 6442 D0 0E02 2388 : MOVL (R4)[R2],R4 ; Get PCB address
00000000'GF 16 0E06 2389 : JSB G^COM$FLUSHATTNS ; Flush AST
DB 11 0E0C 2390 : BRB 20$ ; Continue until all flushed
0E0E 2391 :
0E0E 2392 : ; Release the base table map registers, save the error counters, and
0E0E 2393 : ; deallocate the base table.
0E0E 2394 :
54 24 A5 D0 0E0E 2395 : 25$: MOVL UCB$C_CRB(R5),R4 ; Get CRB address
011C C5 D0 0E12 2396 : MOVL UCB$C_XM_BASEMAP(R5),- ; Set mapping info
```



```

      34 A4      19 OE16 2397      CRBSL_INTD+VECSW_MAPREG(R4)
      OB      19 OE18 2398      27$      ; Br if none
011C C5      01 CE OE1A 2399      RELMPR      ; Release the map registers
      27      13 OE20 2400      MNEGL      #1,UCBSL_XM_BASEMAP(R5) ; Reset mapping info
50      0118 C5 D0 OE25 2401      27$:      MOVL      UCBSL_XM_BASSETAB(R5),R0 ; Get address of base table
      27      13 OE2A 2402      BEQL      30$      ; Br if none
51      50      03 C1 OE2C 2403      ADDL3     #3,R0,R1      ; Set address of error counters
      52      08 D0 OE30 2404      MOVL      #UCBSL_XM_DEVCNT,R2 ; Set number of counters
53      0130 C5 9E OE33 2405      MOVAB     UCB$B_XM_DEVCNT(R5),R3 ; Get address of saved counters
      83      81 80 OE38 2406      28$:      ADDB      (R1)+,(R3)+ ; Add counter to saved counter
      FA 52      F5 OE3B 2407      SOBGTR    R2,28$      ; Loop through counters
      2408      OE3E 2409
      0118 C5      D4 OE3E 2410      CLRL      UCBSL_XM_BASSETAB(R5) ; Reset state to no table
50      F4 A0      9E OE42 2411      MOVAB     -BAS T DATA(R0),R0 ; Reset pointer to start of block
010C C5      0100 8F A0 OE46 2412      ADDW      #BASSETAB_SIZE,UCBSW_XM_QUOTA(R5); Restore quota
      00000000'GF 16 OE4D 2413      JSB      G^COM$DRVDEALMEM ; Deallocate the base table
      2414      OE53 2414      ;
      2415      OE53 2415      ; Release the receive and transmit buffer map registers
      2416      OE53 2416      ;
      57      D4 OE53 2417      30$:      CLRL      R7      ; Init slot number
      2418      OE55 2418      ASSUME     UCBSL_XM_RCV_MAP+<4*MAX_RCV> EQ UCBSL_XM_XMT_MAP
56      00D0 C5 9E OE55 2419      MOVAB     UCBSL_XM_RCV_MAP(R5),R6 ; Get address of mapping slots
      34 A4      86 D0 OE5A 2420      50$:      MOVL      (R6)+,CRBSL_INTD+VECSW_MAPREG(R4) ; Set mapping info
      OA      19 OE5E 2421      BLSS      60$      ; Br if none allocated
      2422      OE60 2422      RELMPR      ; Release the map registers
      FC A6      01 CE OE66 2423      MNEGL     #1,-4(R6) ; Reset mapping info
      2424      OE6A 2424      60$:      CLRBIT    R7,UCBSB_XM_RCV_MAP(R5) ; Clear mapping slot flag
      E6 57      OE      F2 OE70 2425      AOBLS    #MAX_RCV+MAX_XMT,R7,50$ ; Loop through all mapping slots
      2426      OE74 2426      ;
      2427      OE74 2427      ; Deallocate all receive buffers and abort all I/O requests
      2428      OE74 2428      ;
56      0090 C5 9E OE74 2429      90$:      MOVAB     UCB$Q_XM_QUEUES(R5),R6 ; Get address of first queue listhead
      57      08 D0 OE79 2430      MOVL      #UCBSL_XM_QUEUES,R7 ; Get number of queues
      50      00 B6 OF OE7C 2431      95$:      REMQUE    @ (R6),R0 ; Get next I/O packet/buffer
      29      1D OE80 2432      BVS      110$     ; Br if none - queue empty
      OA      OA A0 91 OE82 2433      CMPB      IRP$B_TYPE(R0),S^#DYN$C_IRP ; Is it an I/O packet?
      2434      OE86 2434      BEQL      97$      ; Br if yes
      17      OA A0 91 OE88 2435      CMPB      IRP$B_TYPE(R0),S^#DYN$C_NET ; Is it a receive buffer?
      OF      13 OE8C 2436      BEQL      100$     ; Br if yes
      2437      OE8E 2437      BUG_CHECK NOBUFPCKT,FATAL ; Else, fatal error
      2438      OE92 2438      ;
      53      50 D0 OE92 2439      97$:      MOVL      R0,R3      ; Set I/O packet address
      50      2C 3C OE95 2440      MOVZWL    #SS$ ABORT,R0 ; Set I/O status
      FDD5      30 OE98 2441      BSBW      IO DONE ; Abort the I/O request
      DF      11 OE9B 2442      BRB      95$      ;
      2443      OE9D 2443      ;
      42 A5      A0 OE9D 2444      100$:      ADDW      UCB$W_DEVBUFSIZ(R5),- ; Restore quota
      010C C5      OEAO 2445      UCB$W_XM_QUOTA(R5) ;
      00000000'GF 16 OEA3 2446      JSB      G^COM$DRVDEALMEM ; Deallocate the receive buffer
      D1      11 OEA9 2447      BRB      95$      ;
      2448      OEAB 2448      ;
      56      08 C0 OEAB 2449      110$:      ADDL      #8,R6      ; Increment queue listhead pointer
      CB 57      F5 OEAE 2450      SOBGTR    R7,95$     ; Loop through queues
      2451      OEB1 2451      ;
      2452      OEB1 2452      ; Restore the buffered I/O quota to the starter
      2453      OEB1 2453      ;
```



```
51 50 0110 C5 3C 0EB1 2454 MOVZWL UCBSL_XM_PID(R5),R0 ; Get process index of last starter
    00000000 GF D0 0EB6 2455 MOVL G^SCH$GL_PCBVEC,R1 ; Get address of PCB address vector
    50 6140 D0 0EBD 2456 MOVL (R1)[R0],R0 ; Get PCB address of starter
    60 A0 D1 0EC1 2457 CMPL PCBSL_PID(R0),- ; Still same process?
    0110 C5 12 0EC4 2458 UCBSL_XM_PID(R5)
    16 12 0EC7 2459 BNEQ 140$ ; Br if not - forget it
50 0080 C0 D0 0EC9 2460 MOVL PCBSL_JIB(R0),R0 ; Get JIB address
51 010C C5 3C 0ECE 2461 MOVZWL UCBSW_XM_QUOTA(R5),R1 ; Convert to longword
    20 A0 51 C0 0ED3 2462 ADDL R1,JIBSL_BYTCNT(R0) ; Return byte count quota
    24 A0 51 C0 0ED7 2463 ADDL R1,JIBSL_BYTLM(R0) ; ..and byte limit quota
    010C C5 B4 0EDB 2464 CLRW UCBSW_XM_QUOTA(R5) ; Reset quota
    00D0 8F BA 0EDF 2465 140$: POPR #^M<R4,R6,R7> ; Restore registers
    05 0EE3 2466 RSB
    0EE4 2467
    0EE4 2468 DO_CANCEL: ; Cancel the I/O
    53 56 D0 0EE4 2469 MOVL R6,R3 ; Copy listhead address
    53 63 D0 0EE7 2470 10$: MOVL (R3),R3 ; Get next entry
    56 53 D1 0EEA 2471 CMPL R3,R6 ; At start of list?
    0F 13 0EED 2472 BEQL 20$ ; Br if yes
    0E 10 0EEF 2473 BSBB CHECK_PKT ; Check for match
    F4 12 0EF1 2474 BNEQ 10$ ; Br if no match
    53 63 0F 0EF3 2475 REMQUE (R3),R3 ; Remove IRP from list
    50 2C 9A 0EF6 2476 MOVZBL S^#SS$ ABORT,R0 ; Else, set the I/O status return
    FD74 30 0EF9 2477 BSBW IO_DONE ; Abort the I/O request
    E6 11 0EFC 2478 BRB DO_CANCEL ; Continue from start of list - again
    05 0EFE 2479 20$: RSB ; Return to caller
    0EFF 2480
    0EFF 2481 CHECK_PKT:
    28 A3 52 B1 0EFF 2482 CMPW R2,IRPSW_CHAN(R3) ; Channel match?
    12 12 0F03 2483 BNEQ 20$ ; Br if no
    0C A3 D5 0F05 2484 TSTL IRPSL_PID(R3) ; Is this an Internal IRP?
    08 14 0F08 2485 BGTR 10$ ; Br if NO - PID must match
0110 C5 60 A4 D1 0F0A 2486 CMPL PCBSL_PID(R4),UCBSL_XM_PID(R5) ; Starter's PID?
    05 11 0F10 2487 BRB 20$ ; Done
    0C A3 60 A4 D1 0F12 2488 10$: CMPL PCBSL_PID(R4),IRPSL_PID(R3) ; PIDs match?
    05 0F17 2489 20$: RSB
    0F18 2490
```



```
OF18 2492 .SBTTL DISABLE_MODEM - DISABLE THE MODEM LINE DTR
OF18 2493 :++
OF18 2494 : DISABLE_MODEM - DISABLE THE MODEM
OF18 2495 :
OF18 2496 : Functional description:
OF18 2497 :
OF18 2498 : This routine will clear the DTR line to the modem to hang up
OF18 2499 : any phone connection still active.
OF18 2500 :
OF18 2501 :
OF18 2502 : Inputs:
OF18 2503 :
OF18 2504 : R5 = UCB ADDRESS
OF18 2505 :
OF18 2506 : Outputs:
OF18 2507 :
OF18 2508 : NONE.
OF18 2509 :
OF18 2510 :--
OF18 2511 :
OF18 2512 DISABLE_MODEM:
OF18 2513 : PUSH R1 ; Disable the modem line (DTR)
51 24 A5 DD OF1A 2514 : MOVL UCB$$_CRB(R5),R1 ; Save R1
61 4000 8F B0 OF1E 2515 : ASSUME IDB$$_CSR EQ 0 ; Get CRB address
06 A1 A40B 8F B0 OF1E 2516 : MOVL @CRB$$_INTD+VEC$_IDB(R1),R1 ; Get CSR address
01 A1 82 8F 90 OF22 2517 : MOVW #XM_I_M_MCLR,(R1) ; Master clear the unit
51 8ED0 05 OF27 2518 : MOVW #DROP-DTR,XM_PORT+2(R1) ; Load micro-instruction to drop DTR
OF32 2519 : MOVW #EXECUTE_UC,T(R1) ; Tell controller to execute instruction
OF35 2520 : POPL R1 ; Restore R1
OF36 2521 : RSB ; Return to caller
OF36 2522 :
OF36 2523 :
OF36 2524 XM_END:
OF36 2525 : .END
```


XMDRIVER
Symbol table

- VAX/VMS DMC11/DMR11 Device Driver

K 5

16-SEP-1984 00:26:05 VAX/VMS Macro V04-00
5-SEP-1984 00:20:43 [DRIVER.SRC]XMDRIVER.MAR;1

Page 56
(27)

```

$$$ = 00000020 R 02
$$$TYP = 00000406
$$$WID = 00002000
$$OP = 00000002
ABORTIO = 00000108 R 03
ACBSL_KAST = 00000018
ADDRCVLIST = 000008CE R 03
ALTFDT = 00000208 R 03
ATS_UBA = 00000001
BASETAB_SIZE = 00000100
BAS_B_SPARE = 0000000B
BAS_B_TYPE = 0000000A
BAS_C_HEADER = 0000000C
BAS_Q_SPARE = 00000000
BAS_T_DATA = 0000000C
BAS_W_SIZE = 00000008
BUGS_NOBUFCKT ***** X 03
CANSC_DASSGN = 00000001
CANCEC = 00000D67 R 03
CHANGE_MODE = 000008A6 R 03
CHECK_PKT = 00000EFF R 03
CNTTAB = 00000078 R 03
CNT_BUFSIZ = 00000032
COM$DELATTNAST ***** X 03
COM$DRVDEALMEM ***** X 03
COM$FLUSHATTNS ***** X 03
COM$POST ***** X 03
COM$SETATTNAST ***** X 03
CONTROL_INTR = 00000AB1 R 03
CRBSL_INTD = 00000024
CRBSL_INTD2 = 00000048
CXBSC_HEADER = 00000048
CXBSC_TRAILER = 00000004
DCS_SCOM = 00000020
DDBSL_DDT = 0000000C
DEVSM_AVL ***** X 02
DEVSM_IDV ***** X 02
DEVSM_NET ***** X 02
DEVSM_ODV ***** X 02
DEVICE_ERROR = 00000D18 R 03
DISABLE_MODEM = 00000F18 R 03
DMC_DMR = 00000003
DO_CANCEL = 00000EE4 R 03
DPTSC_LENGTH = 00000038
DPTSC_VERSION = 00000004
DPT$INITAB = 00000038 R 02
DPT$REINITAB = 00000054 R 02
DPT$TAB = 00000000 R 02
DROP_DTR = 0000A40B
DTS_DMC11 = 00000001
DTS_DMR11 = 00000002
DYN$C_CRB = 00000005
DYN$C_DDB = 00000006
DYN$C_DPT = 0000001E
DYN$C_IRP = 0000000A
DYN$C_NET = 00000017
DYN$C_TQE = 0000000F

```

```

DYN$C_UCB = 00000010
EXESABORTIO ***** X 03
EXESALLOCBUF ***** X 03
EXESALONONPAGED ***** X 03
EXESBUFQUOPRC ***** X 03
EXESFINISHIO ***** X 03
EXESFINISHIOC ***** X 03
EXESFORK ***** X 03
EXESGL_ABSTIM ***** X 03
EXESGL_TENUSEC ***** X 03
EXESGL_UBDELAY ***** X 03
EXESGQ_SYSTIME ***** X 03
EXESINSTIMQ ***** X 03
EXESIOFORK ***** X 03
EXESQIODRVPKT ***** X 03
EXESQIORETURN ***** X 03
EXESREADCHK ***** X 03
EXESSNDEVMSG ***** X 03
EXESWRITELOCK ***** X 03
EXECUTE_UC = 00000082
FILLRCVLIST = 000008C6 R 03
FINISH_RCV_IO = 00000C38 R 03
FKBSB_FIPL = 0000000B
FKBSC_LENGTH = 00000018
FKBSL_FR3 = 00000010
FORK_PROC = 00000B84 R 03
FUNCTABLE = 00000038 R 03
FUNCTAB_LEN = 00000040
IDBSL_CSR = 00000000
IDBSL_UCBLST = 00000018
INPUT_DONE = 00000A6D R 03
INTERR = 00000AAC R 03
INTEXIT = 00000AA2 R 03
IOSM_CTRL = 00000200
IOSM_SHUTDOWN = 00000080
IOSM_STARTUP = 00000040
IOSV_ATTNAST = 00000008
IOSV_CLR_COUNT = 0000000A
IOSV_CTRL = 00000009
IOSV_DSABLMBX = 0000000A
IOSV_ENABLMBX = 00000007
IOSV_NOW = 00000006
IOSV_RD_COUNT = 00000008
IOSV_SHUTDOWN = 00000007
IOSV_STARTUP = 00000006
IOS_READLBLK = 00000021
IOS_READPBLK = 0000000C
IOS_READVBLK = 00000031
IOS_SENSECHAR = 0000001B
IOS_SENSEMODE = 00000027
IOS_SETCHAR = 0000001A
IOS_SETMODE = 00000023
IOS_VIRTUAL = 0000003F
IOS_WRITEBLK = 00000020
IOS_WRITEPBLK = 0000000B
IOS_WRITEVBLK = 00000030
IOC$ALOUBAMAP ***** X 03

```

XQ
VO

XMDRIVER
Symbol table

- VAX/VMS DMC11/DMR11 Device Driver L 5

16-SEP-1984 00:26:05 VAX/VMS Macro V04-00
5-SEP-1984 00:20:43 [DRIVER.SRC]XMDRIVER.MAR;1

Page 57
(27)

IOCSLOADUBAMAPA	*****	X	03	NMASC-CTCIR-RBE	=	00000410	
IOCSLOADUBAMAPN	*****	X	03	NMASC-CTCIR-RRT	=	00000406	
IOCSMNTVER	*****	X	03	NMASH-CNT-COU	=	00008000	
IOCSRELMAPREG	*****	X	03	NMASH-CNT-MAP	=	00001000	
IOCSREQCOM	*****	X	03	NMASH-CNT-TYP	=	00000FFF	
IOCSREQMAPREG	*****	X	03	NMASV-CNT-MAP	=	0000000C	
IOCSRETURN	*****	X	03	NMASV-CNT-WID	=	0000000D	
IOCSWFIKPCB	*****	X	03	P1	=	00000000	
IO_DONE	00000C70	R	03	P2	=	00000004	
IPCS_TIMER	= 00000008			P3	=	00000008	
IRPSB_TYPE	= 0000000A			PCBSL_JIB	=	00000080	
IRPSC_LENGTH	= 000000C4			PCBSL_PID	=	00000060	
IRPSL_ARB	= 00000058			POKE_USER	00000CBA	R	03
IRPSL_DIAGBUF	= 0000004C			PORT_INTR	00000A71	R	03
IRPSL_IOST1	= 00000038			PRS_TPL	= 00000012		
IRPSL_IOST2	= 0000003C			RCVFDT	000001AA	R	03
IRPSL_MEDIA	= 00000038			RCV_B_BLKTYPE	0000000A		
IRPSL_PID	= 0000000C			RCV_B_MAPSLOT	0000000B		
IRPSL_SVAPTE	= 0000002C			RCV_L_BACC	0000000C		
IRPSL_UCB	= 0000001C			RCV_L_LINK	00000000		
IRPSV_DIAGBUF	= 00000007			RCV_START	000001E5	R	03
IRPSV_FUNC	= 00000001			RCV_T_DATA	00000048		
IRPSW_BCNT	= 00000032			RCV_W_BLKSIZE	00000008		
IRPSW_BOFF	= 00000030			REGDUMP	00000C97	R	03
IRPSW_CHAN	= 00000028			SCH\$GL_PCBVEC	*****	X	03
IRPSW_FUNC	= 00000020			SCHED_FORK	00000B5B	R	03
IRPSW_STS	= 0000002A			SENSEMODEFDT	000003A6	R	03
JIBSL_BYTCNT	= 00000020			SETMODEFDT	00000231	R	03
JIBSL_BYTLM	= 00000024			SETMODEFDT_LINE	00000321	R	03
LOAD_PORT	00000987	R	03	SHUTDOWN	00000DA5	R	03
LOAD_PORT_ALT	0000099A	R	03	SHUTDOWN_ALT	00000DA7	R	03
LOAD_PORT_AVAIL	00000A16	R	03	SHUT_TIME	= 000F4240		
LS_UCODE	= 00000300			SIZ...	= 00000001		
MASKH	= 00000080			SS\$ABORT	= 0000002C		
MASKL	= 08000000			SS\$ACCVIO	= 0000000C		
MAX_C_BUFSIZE	= 00003FFF			SS\$BADPARAM	= 00000014		
MAX_RCV	= 00000007			SS\$CTRLERR	= 00000054		
MAX_XMT	= 00000007			SS\$DEVACTION	= 000002C4		
MM\$GL_SPTBASE	*****	X	03	SS\$DEVOFFLINE	= 00000084		
MODSM_XM_BSEL1	= 00000080			SS\$ENDOFFILE	= 00000870		
MODSM_XM_HIGH	= 00000001			SS\$INSFMAPREG	= 00000344		
MODSM_XM_RS232	= 00000010			SS\$NORMAL	= 00000001		
MODSM_XM_RS422	= 00000020			STARTIO	0000045E	R	03
MODSV_XM_HIGH	= 00000000			STARTUP	000004C0	R	03
MODSV_XH_INTMOD	= 00000002			START_COMPLETE	00000856	R	03
MODSV_XM_RS232	= 00000004			START_CTRL_ERROR	00000849	R	03
MSG\$XM_ATTN	*****	X	03	START_ERROR	0000084E	R	03
MSG\$XM_DATAVL	*****	X	03	START_RECEIVE	0000092B	R	03
MSG\$XM_SHUTDN	*****	X	03	START_REQ_PORT	00000864	R	03
NMASC-CTCIR-BRC	= 000003E8			START_WAIT_PORT	0000086A	R	03
NMASC-CTCIR-BSN	= 000003E9			TIMEOUT	00000CFE	R	03
NMASC-CTCIR-DBR	= 000003F2			TQESB_RQTYPE	= 0000000B		
NMASC-CTCIR-DBS	= 000003F3			TQESB_TYPE	= 0000000A		
NMASC-CTCIR-DEI	= 000003FC			TQESC_LENGTH	= 00000030		
NMASC-CTCIR-DEO	= 000003FD			TQESC_SSSNGL	= 00000001		
NMASC-CTCIR-LBE	= 00000411			TQESL_FPC	= 0000000C		
NMASC-CTCIR-LRT	= 00000407			TQESL_FR3	= 00000010		

XMDRIVER
Symbol table

M 5
- VAX/VMS DMC11/DMR11 Device Driver

16-SEP-1984 00:26:05 VAX/VMS Macro V04-00
5-SEP-1984 00:20:43 [DRIVER.SRC]XMDRIVER.MAR;1

Page 58
(27)

```
UCBSB_DEVCLASS      = 00000040
UCBSB_DEVTYPE       = 00000041
UCBSB_DIPL          = 0000005E
UCBSB_FIPL          = 0000000B
UCBSB_XM_DCER       = 00000132
UCBSB_XM_DCES       = 00000135
UCBSB_XM_DEVCNT     = 00000130
UCBSB_XM_FKB        = 00000138
UCBSB_XM_HCER       = 00000131
UCBSB_XM_HCES       = 00000134
UCBSB_XM_NBFR       = 00000130
UCBSB_XM_NBFS       = 00000133
UCBSB_XM_RCV_MAP    = 00000108
UCBSB_XM_RCV_MAX    = 0000010A
UCBSB_XM_REPR       = 00000137
UCBSB_XM_REPS       = 00000136
UCBSB_XM_XMT_MAP    = 00000109
UCBSB_XM_XMT_MAX    = 0000010B
UCBSC_LENGTH        = 00000090
UCBSC_XM_DEVCNT     = 00000008
UCBSC_XM_DRVCNT     = 00000004
UCBSC_XM_LENGTH     = 00000152
UCBSC_XM_QUEUES     = 00000008
UCBSL_AMB           = 00000060
UCBSL_CRB           = 00000024
UCBSL_DEVCHAR       = 00000038
UCBSL_DEVDEPEND     = 00000044
UCBSL_DUETIM        = 0000006C
UCBSL_FPC           = 0000000C
UCBSL_IRP           = 00000058
UCBSL_RCVBYTCNT     = 00000120
UCBSL_RCVMSGCNT     = 00000128
UCBSL_SVAPTE        = 00000078
UCBSL_XMTBYTCNT     = 00000124
UCBSL_XMTMSGCNT     = 0000012C
UCBSL_XM_AST        = 00000114
UCBSL_XM_BASEMAP    = 0000011C
UCBSL_XM_BASSETAB   = 00000118
UCBSL_XM_DRVCNT     = 00000120
UCBSL_XM_LSTCSR     = 0000014C
UCBSL_XM_LSTPRT     = 00000148
UCBSL_XM_PID        = 00000110
UCBSL_XM_RCV_MAP    = 000000D0
UCBSL_XM_XMT_MAP    = 000000EC
UCBSM_INT           = 00000002
UCBSM_ONLINE        = 00000010
UCBSM_POWER         = 00000020
UCBSM_TIM           = 00000001
UCBSM_TIMEOUT       = 00000040
UCBSM_XM_FORK_PEND  = 00002000
UCBSM_XM_FORK_XMT   = 00000001
UCBSM_XM_INITED     = 00000008
UCBSM_XM_LOSTERR    = 00001000
UCBSM_XM_NOTIF      = 00000800
UCBSQ_XM_PORT       = 000000A0
UCBSQ_XM_POST       = 000000B8
UCBSQ_XM_QUEUES     = 00000090
```

```
UCBSQ_XM_RCV_BUF    = 000000C0
UCBSQ_XM_RCV_MSG    = 000000C8
UCBSQ_XM_RCV_PND    = 000000B0
UCBSQ_XM_RCV_REQ    = 00000098
UCBSQ_XM_XMT_PND    = 000000A8
UCBSQ_XM_XMT_REQ    = 00000090
UCBSV_ONLINE        = 00000004
UCBSV_POWER         = 00000005
UCBSV_XM_FORK_PEND  = 0000000D
UCBSV_XM_FORK_XMT   = 00000000
UCBSV_XM_INITED     = 00000003
UCBSV_XM_LOSTERR    = 0000000C
UCBSV_XM_NOTIF      = 0000000B
UCBSW_BCNT          = 0000007E
UCBSW_BOFF          = 0000007C
UCBSW_DEVBUSIZ      = 00000042
UCBSW_DEVSTS        = 00000068
UCBSW_ERRCNT        = 00000082
UCBSW_REFC          = 0000005C
UCBSW_STS           = 00000064
UCBSW_XM_MODSIG     = 00000150
UCBSW_XM_QUOTA      = 0000010C
UINST_CNF           = 00002296
UINST_RROM          = 0000814D
UNIT_INIT           = 000000A4 R 03
VASM_BYTE           = 000001FF
VASS_VPN            = 00000015
VASV_VPN            = 00000009
VECSB_DATAPATH      = 00000013
VECSB_NUMREG        = 00000012
VECSL_IDB           = 00000008
VECSL_UNITINIT      = 00000018
VECSW_MAPREG        = 00000010
XMSDDT              = 00000000 RG 03
XMSM_CHR_HDPLX      = 00000004
XMSM_CHR_MBX        = 00000010
XMSM_CHR_MOP        = 00000001
XMSM_CHR_SLAVE      = 00000008
XMSM_ERR_FATAL      = 00010000
XMSM_STS_ACTIVE     = 00000800
XMSV_CHR_LOOPB      = 00000001
XMSV_CHR_MBX        = 00000004
XMSV_STS_ACTIVE     = 0000000B
XMSV_STS_BUFFAIL    = 0000000C
XMTFDT              = 000000D0 R 03
XMT_START            = 0000010E R 03
XMT_START_ALT       = 00000113 R 03
XM_END               = 00000F36 R 03
XM_E_M_LOST         = 00000010
XM_E_M_MOP          = 00000008
XM_E_M_NONEXMEM     = 00000100
XM_E_M_POWER        = 00000400
XM_E_M_PROCERR      = 00000200
XM_E_M_START        = 00000080
XM_E_M_TIMEOUT      = 00000800
XM_E_V_POWER        = 0000000A
XM_E_V_PROCERR      = 00000009
```


XMDRIVER
Symbol table

- VAX/VMS DMC11/DMR11 Device Driver N 5

16-SEP-1984 00:26:05
5-SEP-1984 00:20:43

VAX/VMS Macro V04-00
[DRIVER.SRC]XMDRIVER.MAR;1

Page 59
(27)

```

XM_E_V TIMEOUT      = 00000008
XM_I_CSR             = 00000000
XM_I_M_IEI          = 00000040
XM_I_M_LOOPB        = 00000800
XM_I_M_MCLR          = 00004000
XM_I_M_RCV           = 00000004
XM_I_M_RDI           = 00000080
XM_I_M_ROMI          = 00000200
XM_I_M_ROMO          = 00000400
XM_I_M_RQI           = 00000020
XM_I_M_RUN           = 00008000
XM_I_M_STEPUP        = 00000100
XM_I_V_RQI           = 00000005
XM_O_CSR             = 00000002
XM_O_M_IEO           = 00000040
XM_O_M_RDO           = 00000080
XM_O_V_RCV           = 00000002
XM_O_V_TYPE          = 00000000
XM_PORT              = 00000004
XM_UCODE             = 00000006

```

+-----+
! Psect synopsis !
+-----+

PSECT name	Allocation	PSECT No.	Attributes
. ABS .	00000000 (0.)	00 (0.)	NOPIC USR CON ABS LCL NOSHR NOEXE NORD NOWRT NOVEC BYTE
\$AB\$\$	00000152 (338.)	01 (1.)	NOPIC USR CON ABS LCL NOSHR EXE RD WRT NOVEC BYTE
\$\$\$105_PROLOGUE	00000069 (105.)	02 (2.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC BYTE
\$\$\$115_DRIVER	00000F36 (3894.)	03 (3.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC LONG

+-----+
! Performance indicators !
+-----+

Phase	Page faults	CPU Time	Elapsed Time
Initialization	29	00:00:00.04	00:00:01.11
Command processing	120	00:00:00.44	00:00:05.02
Pass 1	828	00:00:26.80	00:01:32.21
Symbol table sort	0	00:00:03.68	00:00:12.70
Pass 2	505	00:00:06.16	00:00:24.08
Symbol table output	1	00:00:00.23	00:00:02.57
Psect synopsis output	0	00:00:00.04	00:00:00.51
Cross-reference output	0	00:00:00.00	00:00:00.00
Assembler run totals	1485	00:00:37.40	00:02:18.21

The working set limit was 2400 pages.

223463 bytes (437 pages) of virtual memory were used to buffer the intermediate code.

There were 190 pages of symbol table space allocated to hold 3446 non-local and 183 local symbols.

2525 source lines were read in Pass 1, producing 27 object records in Pass 2.

59 pages of virtual memory were used to define 55 macros.

+-----+
! Macro library statistics !
+-----+

Macro library name

Macros defined

\$255\$DUA28:[SHRLIB]NMALIBRY.MLB;1
\$255\$DUA28:[SYS.OBJ]LIB.MLB;1
\$255\$DUA28:[SYSLIB]STARLET.MLB;2
TOTALS (all libraries)

1
34
11
46

3627 GETS were required to define 46 macros.

There were no errors, warnings or information messages.

MACRO/LIS=LISS:XMDRIVER/OBJ=OBJ\$:XMDRIVER MSRC\$:XMDRIVER/UPDATE=(ENH\$:XMDRIVER)+EXECML\$/LIB+SHRLIB\$:NMALIBRY/LIB

0121 AH-BT13A-SE
VAX/VMS V4.0

DIGITAL EQUIPMENT CORPORATION
CONFIDENTIAL AND PROPRIETARY

XMDRIVER
LIS

XMDRIVER
LIS